


COLD ROOM ELECTRICAL PANEL

User Manual



sub-zero[®]
INDIA
www.pvrcontrols.com

sub-zero[®]

CRC-2020

Index		
PARAMETER	DESCRIPTION	Pg. No.
	Introduction	3
	Get to Know Your Controller	4
	Items Included.	4
	Key Introduction	5
	Fault Messages.	6
	LED Indication.	7
	Parameter List.	8
SET POINT	To set the cut-out point of the controller.	8
	To set other parameter	8
P2	To set allowable high temperature limit.	9
P3	To set allowable low temperature limit.	9
P4	To set the differential for compressor restart.	10
P5	To set probe calibration.	10
P6	To set time delay between relay restart time.	10-11
P7	To set duration of defrost.	11
P8	To set defrost frequency.	11
P9	To set power on defrost delay.	11
BUZ	To enable / disable buzzer.	12
AL	This parameter is used to set power on delay for alarm.	12
C-UL	Under load limit for compressor current.	12
C-OL	Over load limit for compressor current.	13
C2	Current sensing delay.	13
D0	To enable or Disable HP sensing.	13
D1	To enable or disable LP sensing.	14
D2	Fault sensing logic.	14

Index		
PARAMETER	DESCRIPTION	Pg. No.
D3	To set LP sensing delay.	14
D4	To set reset mode for HP fault.	15
DI-D	To select AUX or compressor thermal trip digital I/P	15
OPS	To Enable / Disable Oil Pressure Switch (OPS) I/P.	15
E1	To set Compressor Relay status on Probe Failure.	16
TON	To set On cycle at room probe fail.	16
TOFF	To set Off cycle at room probe fail.	16
E7	To set Display at defrosting.	16
LD	To set time delay to switch off the light .	17
PW	To change password.	17
CRH	To view Compressor run Hours.	17
CCRH	Clear Compressor Run Hours.	17
Unit ID	To set Unit ID.	18
LP	To activate Keypad Lock.	18
PO	To enable/disable Power Switch.	18-19
PDIS	To set display at power OFF mode.	19
FS	To restore default settings of the controller.	19
EP	End of programming.	19
	Technical Data	20
	Instruction manual for VMRC-10/3	21-28
	Suggested Wiring Diagram	29
	Caution & Warranty	30-31
		21

Introduction

The CRC-2020 is single set point cold room controller. The Sub-Zero CRC-2020 is aesthetically superior versions of their predecessors.

Features:

The controller controls the defrost in the system based on time based where the compressor is stopped. It is also possible to select the interval between defrosts and a maximum time out after which the defrost is interrupted.

There are safety features which include shutting down the system incase of a fault from a pressure control or similar device.


A series of “safety controls” (delay at start-up, minimum disable time, minimum time between activation) protects the compressors from close starts. In case of probe error or temperature alarm, the instrument signals the event through acoustic signal and by closing the relay contact. By pressing the mute key, the buzzer is silenced.

A number of parameters are displayed alphanumerically to set up the instrument for each specific function.

The CRC-2020 controller can be used for several applications with a measuring range from -50.0°C to 50.0°C.

Computer Connectivity over RS485 and Remote monitoring(Optional).









Get to Know Your Controller



Items included

NO.	ITEMS	QTY
1.	CONTROLLER	1
2.	NTC SENSOR 5 METER	1
3.	CATALOGUE	1
4.	8 X 38 SCREW WITH RAWL PLUG	4






Key Introduction

	Used to enter in manual defrost and to stop defrost if defrosting is ON.
	Used to increment/scroll in Program Mode. When not in any mode if this key is pressed for 2 secs controller will enter in fault log mode.
	Used to come mute the buzzer/Alarm & to exit any mode.
	Used to switch OFF/ON the controller.
	Used to decrement/scroll in Program mode. Used to enter into the program mode.
	Used to enter into the Set mode. Also used as enter key if controller is in Set mode/program mode.
	Used to enter into the Amp. mode where compressor current can be viewed.
	Used to switch OFF/ON the light.

Fault Messages :



Ht	High temperature alarm for Room means, room temperature is equal or above the set value of P2 parameter.
Lt	Low temperature alarm for Room means, room temperature is equal or below the set value of P3 parameter.
PP	Room temperature fail means, Room sensor not connected or out of range.
SPPR	SPPR Fault.
C-OL	Compressor over load fault.
C-UL	Compressor under load fault.
HP	HP fault.
LP	LP fault.
AUX / CTH	Auxiliary fault / Compressor Thermal Fault .
DO	Door Open fault.
OPS	Oil Pressure Switch Fault.

LED Indication

Messages	Mode	Discription
	On Off Flashing	Comp. Relay On. Comp. Relay Off. Comp. Relay Timedelay.
	On Off Flashing	Defrost On. Defrost Off. Defrost in Timedelay.
	On Off	Alarm Relay On. Alarm Relay Off.
	Off On	Power Off. Power On.
	On Off	Light Relay On. Light Relay Off.
R	On Off	R-phase present. R-phase absent.
Y	On Off	Y-phase present. Y-phase absent.
B	On Off	B-phase present. B-phase absent.

Min: MINIMUM Max : MAXIMUM
Fact. Set : FACTORY SETTING(DEFAULT)

Description of parameters and functions.

Sr. No.	Parameter	Parameter setting method	
To set other parameter			
Press & hold SET key for 2 seconds 		Display will show 'SET' and scroll the description of the parameter. To go to other parameters, use UP / DOWN keys.	
01	SP	To set the cut-out point of the controller.	
To change Set Point parameter, press the set key.		Display will change to set value. The set point value can now be changed by using the UP/DOWN key. After desired value, press the SET key & you will see "--" which confirms that the set point has been stored in memory.	
Range			
Min	Max		Fact. Set
P3+0.5°C	P2-0.5°C	0.0°C	
To set other parameter			
Press & hold PRG key for 2 seconds 		Display will show 'P2' and scroll the description of the parameter. To go to other parameters, use UP / DOWN keys.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
01	P2 Parameter	Function : To set allowable high temperature limit.	
	To change P2 parameter, press the set key.		Use UP/DOWN key to set desired value. Once set at a particular value, this will not allow the set point to go above this value and below P3 setting.
	Range		
	Min	Max	Fact. Set
	SP+0.5°C	50.0°C	50.0°C
HT (Message on Display)		Example : Setting this parameter at 50.0°C will not allow the set point to go above 50.0°C also if the temperature reaches 50.0°C, the display will show HT (High Temperature). The alarm will be ON. But at power on till the AL delay is over controller will not generate HT Alarm.	
02	P3 Parameter	Function : To set allowable low temperature limit.	
	To change P3 parameter, press the set key.		Use UP/DOWN key to set desired value. Once set at a particular value, this will not allow the set point to go below this value and above P2 setting.
	Range		
	Min	Max	Fact. Set
	-50.0°C	SP-0.5°C	-50.0°C
LT (Message on Display)		Example : Setting this parameter at -50.0°C will not allow the set point to go below -50.0°C also if the temperature reaches -50.0°C, the display will show LT (Low Temperature). The alarm will be ON.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
03	P4 Parameter	Function : To set the differential for compressor restart.	
	To change P4 parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		
	Min	Max	Fact. Set
	0.5°C	20.0°C	2.0°C
		Example(Cooling Mode) : If the set point is set at 10.0°C and differential is set at 2.0°C, then when the system reaches 10.0°C, the comp. relay will cutout. Since the differential is 2.0°C, the comp. Relay will cutin at 12.0°C (10.0°C + 2.0°C).	
04	P5 Parameter	Function : To set probe calibration.	
	To change P5 parameter, press the set key.		Use UP/DOWN keys to set desired value. In time it may be possible that the display may be offset by a degree or so. To compensate for this error, you may need to add or minus the degrees required to achieve the correct temperature.
	Range		
	Min	Max	Fact. Set
	-10.0°C	10.0°C	0.0°C
		Example : The temperature on the display is 28.0°C, whereas the actual temperature is 30.0°C. You will need to set this parameter to 2.0°C, which means that once out of the programming parameter, the display will show the temperature 30.0°C (28.0°C + 2.0°C).	
05	P6 Parameter	Function : To set time delay between relay restart time.	
	To change P6 parameter, press the set key.		Use UP/DOWN keys to set desired value. This parameter is used to protect the fan from restarting in a short period of time and can be set between 0 to 20 minutes.
	Range		
	Min	Max	Fact. Set
	1 Min	20 Min	3 Min
		Example : If this parameter is set at 3 minutes, the compressor will cut off at the set temperature, but will not restart for a minimum of 3 minutes, even if the differential is achieved earlier. This	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
		parameter is good to protect the life of the compressor when there are power fluctuations and the compressor is switched off and on within a few seconds.	
06	P7 Parameter	Function : To set duration of defrost.	
	To change the P7 Parameter parameter, press the set key.	Use UP/DOWN keys to set desired value. This is maximum amount of time allowed for defrost. If set to 0, there will be no defrost cycle.	
Range			
	Min	Max	Fact. Set
	0 Min	99 Min	30 Min
	Example : If P7 is set to 30 Mins and P8 parameter is set to 1 Hr. then after every 1 Hr defrosting will take place for 15 mins.		
07	P8 Parameter	Function : To set defrost frequency.	
	To change the P8 Parameter parameter, press the set key.	Use UP/DOWN keys to set desired value. This is the amount of time between two defrost cycles.	
Range			
	Min	Max	Fact. Set
	1 Hr	31 Hrs	6 Hr
	Example : same as P7 parameter.		
08	P9 Parameter	Function : To set power on defrost delay.	
	To change the P9 Parameter parameter, press the set key.	Use UP/DOWN keys to set desired value. This is the amount of time at power on after which defrosting will take place once.	
Range			
	Min	Max	Fact. Set
	0 Min	99 Min	30 Min
	Example : If P9 parameter is 30 mins then at power after 30 mins defrosting will take place once.		

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
09	BUZ Parameter	Function : To enable / disable buzzer.	
	To change the BUZ Parameter parameter, press the set key.	Use UP/DOWN keys to set desired value. Example: ENB : Buzzer enabled. DIS : Buzzer disabled.	
Range			
	Min	Max	Fact. Set
	DIS	ENB	ENB
10	AL Parameter	Function : This parameter is used to set power on delay for alarm.	
	To change the AL Parameter parameter, press the set key.	Use UP/DOWN keys to set desired value. Example : If you set this parameter to 30, once the power is switched on, the alarm will not activate for 30 minutes after the power is switched on. This is most useful to avoid the nuisance alarms when the ambients are high when the machine is switched on after a long time.	
Range			
	Min	Max	Fact. Set
	0 Min	99 Min	30 Min
11	C-UL Parameter	Function : Under load limit for compressor current.	
	To change the C-UL parameter, press the set key.	Use UP/DOWN keys to set desired value. Example : If C-UL= 1.0A and compressor current is less than 1.0A then and exists till C2 current sensing delay then it is registered as UL fault. Compressor will get OFF on this fault. If after 3 retries within 1 Hour current drawn is still less than 1.0Amp the controller will trip the compressor on fault and activate respective alarm relay. Also display will flash 'C-UL'. Controller will go in manual reset mode.	
Range			
	Min	Max	Fact. Set
	0.0A	(C-OL -1.0)A	1.0A

Description of parameters and functions.				
Sr. No.	Parameter	Parameter setting method		
12	C-OL Parameter	Function : Over load limit for compressor current.		
	To change the C-OL parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			Example : If C-OL= 10 A and compressor current is greater than 10 A then and exist till C2 current sensing delay then C-OL fault exists and flash on display. Compressor will be tripped on this fault. NOTE : According to the compressor current, set Overload value.
	Min	Max	Fact. Set	
	(C-UL +1.0) A	30.0A	10.0A	
13	C2 Parameter	Function : Current sensing delay.		
	To change the C2 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			Example : If C2 = 5 sec then, any current fault will be valid only when it exists for more than 5 sec.
	Min	Max	Fact. Set	
	5 Sec	60 Sec	5 Sec	
14	D0 Parameter	Function : To enable or Disable HP sensing.		
	To change the D0 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			Example : If this parameter is set to ENB : HP sensing is enabled. DIS : HP sensing is disabled Setting this parameter to disable will ignore HP fault for compressor. If this parameter is set to Enable then controller will detect HP trip.
	Min	Max	Fact. Set	
	DIS	ENB	ENB	

Description of parameters and functions.				
Sr. No.	Parameter	Parameter setting method		
15	D1 Parameter	Function : To enable or disable LP sensing.		
	To change D1 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			Example: If this parameter is set to ENB : LP sensing is enabled. DIS : LP sensing is disabled. Setting this parameter to disable will ignore LP fault for compressor. If this parameter is set to Enable then controller will detect LP trip.
	Min	Max	Fact. Set	
	DIS	ENB	ENB	
16	D2 Parameter	Function : Fault sensing logic.		
	To change D2 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			0V : 0V at HP/LP/AUX input will be sensed as fault and trip the compressor. 230V : 230V at HP/LP/AUX input will be sensed as fault and trip the compressor.
	Min	Max	Fact. Set	
	0V	230V	0V	
17	D3 Parameter	Function : To set LP sensing delay.		
	To change D3 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			Example : If this parameter is set to 30 sec, then LP fault will be sensed only when it present continuously for 30 Secs.
	Min	Max	Fact. Set	
	0 Sec	180 Sec	30 Sec	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
18	D4 Parameter	Function : To set reset mode for HP fault.	
To change D4 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
MAN	AUTO	AUTO	
		MAN : Manual Mode. AUTO : Auto mode. If this parameter set to "MAN" mode HP fault will be cleared only after pressing reset key for 2 seconds. If this parameter is set to "AUTO" mode HP fault will be cleared automatically when it is healthy.	
19	DI-D Parameter	Function : To select AUX or compressor thermal trip digital I/P	
To change the DI Parameter parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
AUX	CTH	AUX	
		If Selected as "AUX" then at fault it will display "AUX" on display. If Selected as "CTH" then at fault it will display "CTH".	
20	OPS Parameter	Function : To Enable / Disable OPS I/P.	
To change the OPS Parameter parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
DIS	ENB	ENB	
		ENB : OPS I/P is enabled. DIS : OPS I/P is disabled.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
21	E1 Parameter	Function : To set Compressor Relay status on Probe Failure.	
To change E1 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
ON	OFF	CYC	
		When set to ON : Relay will stay ON. CYC : Relay performs a duty cycle of as per TON & TOFF . OFF : Relay will stay OFF.	
22	TON Parameter	Function : To set On cycle at room probe fail.	
To change TON parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
1 Min	30 Min	10 Min	
		At room probe fail condition when E1 parameter is selected as 'CYC' then the on cycle is specified by Ton parameter.	
23	TOFF Parameter	Function : To set Off cycle at room probe fail.	
To change TON parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
1 Min	30 Min	4 Min	
		At room probe fail condition when E1 parameter is selected as 'CYC' then the Off cycle is specified by Ton parameter.	
24	E7 Parameter	Function : To set Display at defrosting.	
To change E7 parameter, press the SET key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
TEMP	DEFR	TEMP	
		TEMP : At defrosting temperature will be displayed. DEFR : At Defrosting 'Defrost ON' will scroll.	

Description of parameters and functions.													
Sr. No.	Parameter	Parameter setting method											
25	LD Parameter	Function : To set time delay to switch off the light .											
	To change LD parameter, press the SET key.		Use UP/DOWN keys to set desired value.										
	<table border="1"> <thead> <tr> <th colspan="3">Range</th> </tr> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>0 Min</td> <td>30 Min</td> <td>7 Min</td> </tr> </tbody> </table>			Range			Min	Max	Fact. Set	0 Min	30 Min	7 Min	This parameter is used set the time delay to automatically switch off the light. If LD is set to 0 then this parameter is disabled.
	Range												
Min	Max	Fact. Set											
0 Min	30 Min	7 Min											
			Example : If this parameter is set to 7 mins then, when light is switched on after 7 mins it will be switch off automatically.										
26	PW Parameter	Function : To change password.											
	To change the PW parameter, press the set key.		Use UP/DOWN key to change the password.										
	<table border="1"> <thead> <tr> <th colspan="3">Range</th> </tr> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>9999</td> <td>0000</td> </tr> </tbody> </table>			Range			Min	Max	Fact. Set	0	9999	0000	User can enter into program mode only if correct password is entered. If the password is wrong it will show 'INVALID PASSWORD'.
	Range												
Min	Max	Fact. Set											
0	9999	0000											
27	CRH Parameter	Function : To view Compressor run Hours.											
				It will display compressor run hours. It's a read only parameter.									
28	CCRH	Function : Clear Compressor Run Hours.											
				If this parameter is set to 'YES' compressor run hours (CRH) are cleared.									
	<table border="1"> <thead> <tr> <th colspan="3">Range</th> </tr> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>NO</td> <td>YES</td> <td>NO</td> </tr> </tbody> </table>			Range			Min	Max	Fact. Set	NO	YES	NO	
	Range												
Min	Max	Fact. Set											
NO	YES	NO											

Description of parameters and functions.													
Sr. No.	Parameter	Parameter setting method											
29	ID Parameter	Function : To set Unit ID.											
	To change Unit ID parameter, press the SET key.		This parameter is used to set the Unit ID of the device.										
	<table border="1"> <thead> <tr> <th colspan="3">Range</th> </tr> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>240</td> <td>-</td> </tr> </tbody> </table>			Range			Min	Max	Fact. Set	1	240	-	
	Range												
Min	Max	Fact. Set											
1	240	-											
30	LP	Function: To activate Keypad Lock.											
	To change LP parameter, press the set key.		This parameter can lock the keypad so that tempering is not possible by bystanders.										
	<table border="1"> <thead> <tr> <th colspan="3">Range</th> </tr> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>NO</td> <td>YES</td> <td>NO</td> </tr> </tbody> </table>			Range			Min	Max	Fact. Set	NO	YES	NO	NO : deactivates keypad lock. YES : activates keypad lock.
	Range												
Min	Max	Fact. Set											
NO	YES	NO											
			On activation, all the parameters can only be viewed, but not modified. If the keypad is locked "LOCK" message will be displayed..										
31	PO Parameter	Function : To enable/disable Power Switch.											
	To change PO parameter, press the SET key.		Use UP/DOWN keys to get desired value & press SET key to confirm.										
	<table border="1"> <thead> <tr> <th colspan="3">Range</th> </tr> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>DIS</td> <td>ENB</td> <td>DIS</td> </tr> </tbody> </table>			Range			Min	Max	Fact. Set	DIS	ENB	DIS	DIS : Disable power switch ENB : Enables power switch
	Range												
Min	Max	Fact. Set											
DIS	ENB	DIS											
			Controller has power switch, which if enable puts controller in active or stand by state. If press foe 2 seconds controller will go in stand by state. if press for 2 seconds controller will go in stand by mode, display will be as per "PDIS" parameter. To again switch to ACTIVE WORKING										

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
		MODE, press power switch again for 2 seconds. All leds and display will flash and enter into NORMAL WORKING MODE.	
32	PDIS Parameter	Function : To set display at power OFF mode.	
	To change PDIS parameter, press the SET key.	Use UP/DOWN keys to set desired value.	
	Range		
	Min	Max	Fact. Set
	LED	TEMP	LED
	At power OFF mode power OFF LED will glow & display will be as below, LED : Display Will be Blank. OFF : Display will show OFF. TEMP : Display will show Temperature.		
33	FS Parameter	Function : To restore default settings of the controller.	
	To change FS parameter, press the SET key.	Use UP/DOWN keys to set desired value.	
	Range		
	Min	Max	Fact. Set
	NO	YES	NO
	When set to YES all parameters are programmed to factory values. Useful to debug setting related problems.		
34	EP Parameter	Function: To exit programming.	
	To exit programming parameter, press the SET key.	Once the set key is pressed, the controller goes into the normal mode and displays the Room Temperature and all settings are recorded.	

Technical Data

Housing	: Plastic / Sheet Metal (as per customer requirement)
Dimensions	: Plastic : (H)400 x (W) 300 x (D)135 mm : Sheet Metal : (H)450 x (W) 400 x (D)200 mm
Mounting Connection	: Wall mounting. : Spring clamp terminal block. 4 sq. mm wire.
Display	: 4 Digit, 1" Dot matrix Display and 8 LEDs for indication.
Data Storage	: Non-Volatile EEPROM Memory.
Power Input (Options)	: 415Vac +/-10%, 50-60Hz. 3Phase Supply with Neutral
Operating Temp	: 5°C to 50°C(non-condensing).
Storage temp	: -20°C to 70°C(non-condensing).
Output	:
Compressor Relay	: 5A/230vac
Evap. Relay	: 5A/230vac
Light Relay	: 5A/230Vac.
Alarm Relay	: 5A/230Vac.
Sensors :	
1) Temperature sensor:	
Sensor Type	: NTC Thermistor.
Resolution	: 0.1°C.
Accuracy	: +/-1°C.
Probe Tolerance at 25°C	: +/-0.3°C.
Range	: -50.0°C to 50.0°C.
Analog I/p:	
Compressor current (R,Y,B)	
Resolution	: 0.1Amp.
Accuracy	: +/-1 Amp.
Digital Inputs:	
HP, LP, Auxillary, Door, Sppr, OPS, R-Ph, Y-Ph, B- Ph.	
Buzzer	: Internal
RS485 Connectivity	: Modbus RTU Protocol Baud Rate : 9600 Device ID : 1 (By Default)

Instruction Manual
LVM (Line Voltage Monitor) Three Phase VMRC-10/3

Index


PARAMETER	DESCRIPTION	Pg. No.
	Introduction	22
	Get to know your Controller.	22
	To set program mode.	23
<i>rEF</i>	To set Reference Voltage.	23
<i>oU</i>	To set Overvoltage Limits.	23
<i>uU</i>	To set Undervoltage Limits.	24
<i>unb</i>	To set Un Balance Value.	24
<i>ttd</i>	To set Time Delay.	24
<i>tdr</i>	To set fault recover delay.	25
<i>CrY</i>	To set Calibration of Voltage.	25
<i>CrYb</i>	To set Calibration of Voltage.	25
<i>Crb</i>	To set Calibration of Voltage.	26
<i>dSP</i>	To set Display mode.	26
<i>FS</i>	To Restore factory defaults.	26
<i>End</i>	End programming.	27
	Technical Data.	28
	Front View & Connection Diagram.	28


Introduction

VMRC-10/3 is three phase Line voltage monitor (LVM) used to protect device from Single Phasing, voltage unbalance, phase reversal and under/over voltage. It shows real time voltages between phase and neutral.

There is an Output of alarm relay is given to the controller as SPPR input. Features are easily understood by examples in the instruction below.

Get to Know Your Controller



Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
To set other parameter			
Press & hold PRG key for 2 seconds 		Display will show 'rEF' and scroll the description of the parameter. To go to other parameters, use up / down keys.	
01	<i>rEF</i> PARAMETER	Function : To set Reference voltage.	
To change the rEF Parameter, press the set key.		Use UP/DOWN keys to set desired value. Base reference voltage to calculate under voltage and over voltage values.	
Range			
Min	Max	Fact. Set	
381V	415V	415V	
Example : If dsP is L-L then Min= 381V, Max=415V.			
02	<i>oV</i> PARAMETER	Function : To set Overvoltage Limits.	
To change the oV parameter, press the set key.		Use UP/DOWN keys to set desired value. If the a/c voltages goes above this limit will trip respective a/c on Overvoltage("Ov") fault.	
Range			
Min	Max	Fact. Set	
5V	75V	35V	
Example : Over voltage is calculated depending on Reference voltage + Ov value. i.e. Ov Set Point = Ref + Ov , When controller trip on Ov Fault it will recover when input voltage fall below (Ref - (Ov /2).			

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
03	<i>uV</i> PARAMETER	Function : To set Undervoltage Limits.	
To change the uV parameter, press the set key.		Use UP/DOWN keys to set desired value. If the a/c voltages goes below this limit will trip respective a/c on undervoltage("Uv") fault.	
Range			
Min	Max	Fact. Set	
5V	75V	35V	
Example : Under voltage is calculated depending on Reference voltage - Uv value. i.e Uv Set Point = Ref - Uv , When controller trip on Uv Fault it will recover when input voltage above (Ref – (Uv/2).			
04	<i>unb</i> PARAMETER	Function : To set Un Balance value.	
To change the unb parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
10V	120V	60V	
Unbalance fault raised when voltage difference between any of two phases goes above Unb value and recovers when the difference is less than (UNB/2).			
05	<i>ttd</i> PARAMETER	Function : To set time delay.	
To change the ttd parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0Sec	60Sec	10Sec	
Time delay provided to avoid false triggering, when any fault last more than TTD value then only fault is raised and this fault is applicable to Under voltage, Over voltage and Unbalance fault.(i.e., In case of Phase Loss or Phase sequence fault alarm will come immediately).			

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
06	<i>Ldr</i> PARAMETER	Function : To set fault recover delay.	
To change the tdr parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		Time delay provided to add delay in fault recover time, to avoid sudden fault triggering and reset.	
Min	Max	Fact. Set	
0Sec	240Sec	10Sec	
07	<i>CrY</i> PARAMETER	Function : To set calibration of voltage for r-y or r-n phase.	
To change the CrY Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for r-y. When dsP is L-n then it sets calibration for r-n.	
08	<i>CyB</i> PARAMETER	Function : To set calibration of voltage for y-b or y-n phase.	
To change the CyB parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for y-b. When dsP is L-n then it sets calibration for y-n.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
09	<i>CrB</i> PARAMETER	Function : To set calibration of voltage for r-b or b-n phase.	
To change the CrB parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for r-b. When dsP is L-n then it sets calibration for b-n.	
10	<i>dsP</i> PARAMETER	Function : To set view display mode.	
To change the dsP parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		There are two type of display output, Line to Line Voltage (L-L) and Line to Neutral (L-n), Depending on this parameter REF parameter also changes.	
Min	Max	Fact. Set	
L-L	L-n	L-L	
11	<i>FS</i> PARAMETER	Function : To restore the default settings of the controller.	
To change the FS parameter, press the set key.		Use UP/DOWN keys to set desired value. When set to 1, all parameters are programmed to factory values.	
Range			
Min	Max	Fact. Set	
nO	YES	nO	

Description of parameters and functions.		
Sr. No.	Parameter	Parameter setting method
12	End PARAMETER	Function :To end programming.
	To change the end parameter, press the set key.	Once the set key is pressed, the controller goes into the normal mode and displays the voltage readings.

Technical Data

Main Functions : Voltage Monitoring.
Phase Sequence Monitoring.
Phase Loss and Phase Unbalance detection.
Uv and Ov Detection.
Settable Uv and Ov Parameter.

Dimensions : Front : 69.3mm X 44.3mm,
Depth : 72.3 mm

Input : R, Y, B Phases and Neutral Input.


Output : Alarm Relay : 5A Resistive.


Application : :Voltage and phase sequence monitoring and controlling.
Under voltage and Over voltage detection.

General Specification :
Input Voltage Range from 100VAC to 265VAC.

Mounting : : Din rail mounting.

Connections : : Screw terminals : $\leq 2.5\text{sqmm}$ one wire/terminal only.





1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	
R	Y	B	R	Y	B	N	ROOM PROBE		+ -		L	N	L	N	L	N	L	N	OUT	IN	OUT	IN	HP / LP OUT	HP IN	LP IN		GND	IN
COMP.											LIGHT		ALARM		FRAME HEATER		CCH		OPS		AUX. / CTH		HP / LP OUT	HP IN	LP IN		↑	

SUGGESTED CONNECTOR STICKER FOR PANEL WITH CRC-2020

Controller

Controller should be installed in a place protected by vibration, water and corrosive gasses and where ambient temperature does not exceed the values specified in the technical data.

Probe

To give a correct reading, the probe must be installed in a place protected from thermal influences, which may affect the temperature to be controlled.

Caution

WIRING : The probe and its corresponding wires should never be installed in a conduit next to control or power supply lines. The electrical wiring should be done as shown in the diagram. The power supply circuit should be connected to a protection switch.

WARNING : Improper wiring may cause irreparable damage and personal injury. Kindly ensure that wiring is done by qualified personnel only.

Maintenance : Cleaning : Clean the surface of the controller with a soft moist cloth. Do not use abrasive detergents, petrol, alcohol or solvents.

Notice

The information in this document is subject to change in order to improve reliability, design or function without prior notice and does not represent a commitment on the part of the company. In no event will the company be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company.

Disclaimer

This manual & its contents remain the sole property of PVR Controls, India and shall not be reproduced or distributed without authorization. Although great care has been taken in the preparations of this document, the company or its vendors in no event will be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company. PVR Controls reserves the right to make and changes or improvements without prior notice.

Warranty

This product is warranted against defects in materials and workmanship for a period of one year from the date of purchase. During the warranty period, product determined by us to be defective in form or function will be repaired or, at our option, replaced at no charge. This warranty does not apply if the product has been damaged by accident, abuse, and misuse or as a result of service or modification other than by the company. This warranty is in lieu of any other warranty expressed or implied. In no event shall the company be held liable for incidental or consequential damages, such as lost revenue or lost business opportunity arising from the purchase of this product.

OUR OTHER PRODUCTS



INDIA

Cold Room Controller

Chiller Controller

Two Compressors Controller

Heating Controller

Humidity Controller

Pressure Controller

The logo for CASTLE, featuring the brand name in a bold, uppercase, sans-serif font with a registered trademark symbol (®) to the upper right.

Ball Valves

Globe Valves

Hand Valves

Flow Switches

Solenoid Valves