


COLD ROOM ELECTRICAL PANEL

User Manual



Index		
PARAMETER	DESCRIPTION	Pg. No.
	Features	4
	Items Included.	5
	Key Introduction	6
	Fault Messages.	7
	LED Indication.	8
	Parameter List.	9
SET POINT	To set the cut-out point of the controller.	9
QFS	To set the quick freeze set point.	9
EXIT	End of set mode	9
	To set other parameter	9
P2	To set allowable high temperature limit.	10
P3	To set allowable low temperature limit.	10
P4	To set the differential for compressor restart.	10
P5	To set probe calibration.	11
P6	To set time delay between relay restart time.	11
P7	To set duration of defrost.	12
P8	To set defrost frequency.	12
P9	To set power on defrost delay.	12
P10	To set type of defrost.	13
P11	To set drip time for defrost.	13
P12	To set type of computation for defrost time.	13
P13	To set defrost stop temperature.	14
DI-D	To select AUX or compressor thermal trip digital I/P	14
OPS	To Enable / Disable Oil Pressure Switch (OPS) I/P.	14

Index		
PARAMETER	DESCRIPTION	Pg. No.
QFD	To set quick freeze duration.	15
CND6	To set condenser on delay time.	15
CND7	To set condenser status at hot gas defrost.	15
L1	To set Evaporator Fan stop temperature.	16
L2	To set Evaporator Restart Delay.	16
L3	To set Evaporator Fan status at compressor off.	16
L4	To set Evaporator Fan differential.	16
L5	To set Evaporator probe calibration.	17
L7	To set Evaporator Fan status at Door open condition.	17
L8	To set Evap Fan status during defrost.	17
BUZ	To enable / disable buzzer.	17
AL	Alarm Relay Enable / Disable.	18
ADT	HT Power ON alarm delay.	18
ADD	Alarm/Buzzer output delay at Door open	18
THD	Temperature Hold Duration at Door open	18-19
C-UL	Under load limit for compressor current.	19
C-OL	Over load limit for compressor current.	19
C2	Current sensing delay.	20
D0	To enable or Disable HP sensing.	20
D1	To enable or disable LP sensing.	20
D2	Fault sensing logic.	21
D3	To set LP sensing delay.	21
D4	To set reset mode for HP fault.	21
E1	To set Compressor Relay status on Probe Failure.	22

Index		
PARAMETER	DESCRIPTION	Pg. No.
TON	To set On cycle at room probe fail.	22
TOFF	To set Off cycle at room probe fail.	22
E7	To set Display at defrosting.	22
E8	Defrost duration during Coil probe failure.	23
LD	To set time delay to switch off the light .	23
LSD	Light ON at Door open	23
PDN	To activate Solenoid Valve relay.	23-24
PW	To change password.	24
CRH	To view Compressor run Hours.	24
CCRH	Clear Compressor Run Hours.	24
ID	To set Unit ID.	25
LP	To activate Keypad Lock.	25
PO	To enable/disable Power Switch.	25
PDIS	To set display at power OFF mode.	26
FS	To restore default settings of the controller.	26
EP	End of programming.	26
	Technical Data	27
	Instruction Manual for LVM VMRC-10/3	28-35
	Suggested Wiring Diagram	36
	Caution & Warranty	37-38

Features:


This controller controls the defrost in the system based on either an electrical heater where the compressor is stopped, or at cycle inversion using warm gas where the compressor keeps on working.

There are safety features which include shutting down the system incase of a fault from a pressure control or similar device.

A series of “safety controls” (delay at start-up, minimum disable time, minimum time between activation) protects the compressors from close starts. In case of probe error or temperature alarm, the instrument signals the event through acoustic signal and by closing the relay contact. By pressing the mute key, the buzzer is silenced.

A number of parameters are displayed alphanumerically to set up the instrument for each specific function.











Computer Connectivity over RS485 and Remote monitoring (Optional).

Single Operation Quick Freeze Mode(Press  key for 2 sec), set system in quick freeze mode which is time based for that period new set point will be lower than running set point and system will try to achieve that set point, after time period over set point will be normal set point.

Items included

NO.	ITEMS	QTY
1.	CONTROLLER	1
2.	NTC SENSOR 5 METER	2
3.	CATALOGUE	1
4.	8 X 38 SCREW WITH RAWL PLUG	4











Key Introduction



	Used to enter in manual defrost and to stop defrost if defrosting is ON.
	Used to increment / scroll UP in Program Mode. When not in any mode if this key is pressed for 2 secs controller will enter in display Probe mode where Evap temperature can be viewed.
	Used to come mute the buzzer/Alarm & to exit any mode.
	Used to enter in fault log mode.
	Used to switch OFF/ON the controller.
	Used to enter in quick freeze mode.
	Used to decrement / scroll down in Program mode. Used to enter into the program mode.
	Used to enter into the Set mode. Also used as enter key if controller is in Set mode/program mode. Also used to save changed value.
	Used to enter in display Amp. mode where compressor current can be viewed.
	Used to switch OFF/ON the light.

Fault Messages :

Ht	High temperature alarm for Room temperature means, room temperature is equal or above the set value of P2 parameter.
Lt	Low temperature alarm for Room temperature means, room temperature is equal or below the set value of P3 parameter.
PP	Room temperature fail means, Room sensor not connected or out of range.
E-PP	Evaporator temperature fail means, Evaporator sensor not connected or out of range.
DO	Door Input Fault.
SPPR	SPPR Fault.
C-OL	Compressor over load fault.
C-UL	Compressor under load fault.
HP	HP fault.
LP	LP fault.
AUX/CTH	Auxiliary fault / Compressor Thermal Fault .
OPS	Oil Pressure Switch Fault.
C-PD	Compressor switched ON for Pump down in manual defrost

LED Indication

Messages	Mode	Discription
	ON OFF Flashing	Comp. Relay ON. Comp. Relay OFF. Comp. Relay Time delay.
	ON OFF	Cond. Relay ON. Cond. Relay OFF.
	ON OFF Flashing	Evap. Relay ON. Evap. Relay OFF. Evap. Relay Time delay.
	ON OFF Flashing	Defrost Relay ON. Defrost Relay OFF. Defrost Relay Time delay.
	ON OFF	LSV Relay ON. LSV Relay OFF.
	ON OFF	Alarm Relay ON. Alarm Relay OFF.
	Flashing	Controller is in drip time.
	ON OFF	Controller is in quick freeze mode. Controller is not in quick freeze mode.
	OFF ON	Power OFF. Power ON.
	ON OFF	Light Relay ON. Light Relay OFF.
R	ON OFF	R-phase present. R-phase absent.
Y	ON OFF	Y-phase present. Y-phase absent.
B	ON OFF	B-phase present. B-phase absent.

Min: MINIMUM Max : MAXIMUM Fact. Set : FACTORY SETTING(DEFAULT)		
Description of parameters and functions.		
Sr. No.	Parameter	Parameter setting method
SET MODE		
To set other parameter Press & hold SET key for 2 seconds 		Display will show 'SP' and scroll the description of the parameter. To go to other parameters, use UP / DOWN keys. After desired value, press the SET key & you will see "----" which confirms that the parameter value has been stored in memory.
01	SP	To set the cut-out point of the controller.
To change Set Point parameter, press the set key.		Display will change to set value. The set point value can now be changed by using the UP/DOWN key.
Range		
Min	Max	Fact. Set
QFS+0.5	P2-0.5°C	-20.0°C
02	QFS	To set the quick freeze set point.
To change QFS parameter, press the set key.		Use UP/DOWN keys to set desired value.
Range		
Min	Max	Fact. Set
P3+0.5	SP-0.5	-25.0°C
03	EXIT	End of set mode
PROGRAM MODE		
To set other parameter Press & hold PRG key for 2 seconds 		Display will show '0000'. Set correct password to enter into program mode. The display will show 'P2' and scroll the description of the parameter. To go to other parameters, use UP / DOWN keys. After desired value, press the SET key & you will see "----" which confirms that the parameter value has been stored in memory.

00

Description of parameters and functions.				
Sr. No.	Parameter		Parameter setting method	
01	P2 Parameter		Function : To set allowable high temperature limit.	
	To change P2 parameter, press the set key.		Use UP/DOWN key to set desired value. Once set at a particular value, this will not allow the set point to go above this value and below P3 setting.	
	Range			
	Min	Max		Fact. Set
	SP+0.5°C	50.0°C		50.0°C
HT (Message on Display)		Example : Setting this parameter at 50.0°C will not allow the set point to go above 50.0°C also if the temperature reaches 50.0°C, the display will show HT (High Temperature). The alarm will be ON. But at power on till the ADT delay is over controller will not generate HTAlarm.		
02	P3 Parameter		Function : To set allowable low temperature limit.	
	To change P3 parameter, press the set key.		Use UP/DOWN key to set desired value. Once set at a particular value, this will not allow the set point to go below this value and above P2 setting.	
	Range			
	Min	Max		Fact. Set
	-40.0°C	QFS-0.5°C		-40.0°C
LT (Message on Display)		Example : Setting this parameter at -40.0°C will not allow the set point to go below -40.0°C also if the temperature reaches -40.0°C, the display will show LT (Low Temperature). The alarm will be ON.		
03	P4 Parameter		Function : To set the differential for compressor restart.	
	To change P4 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			
	Min	Max		Fact. Set
	0.5°C	20.0°C		2.0°C
		Example(Cooling Mode) : If the set point is set at 10.0°C and differential is set at 2.0°C, then when the system reaches 10.0°C, the comp. relay will cutout. Since the differential is 2.0°C, the comp. Relay will cutin at 12.0°C (10.0°C + 2.0°C).		

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
04	P5 Parameter	Function : To set room probe calibration.	
To change P5 parameter, press the set key.		Use UP/DOWN keys to set desired value. In time it may be possible that the display may be offset by a degree or so. To compensate this error, you may need to add or minus the degrees required to achieve the correct temperature.	
Range		Example : The temperature on the display is 28.0°C, whereas the actual temperature is 30.0°C. You may need to set this parameter to 2.0°C, which means that once out of the programming parameter, the display will show the temperature 30.0°C (28.0°C + 2.0°C).	
Min	Max		
-10.0°C	10.0°C		
05	P6 Parameter	Function : To set time delay between compressor relay restart time.	
To change P6 parameter, press the set key.		Use UP/DOWN keys to set desired value. This parameter is used to protect the fan from restarting in a short period of time and can be set between 0 to 20 minutes.	
Range		Example : If this parameter is set at 3 minutes, once compressor will cut off at the set temperature, it will not restart for a minimum of 3 minutes, even if the differential is achieved earlier. This parameter is good to protect the life of the compressor when there are power fluctuations and the compressor is switched off and on within a few seconds.	
Min	Max		
1 Min	20 Min		

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
06	P7 Parameter	Function : To set duration of defrost.	
To change the P7 parameter, press the set key.		Use UP/DOWN keys to set desired value. This is maximum amount of time allowed for defrost. If set to 0, there will be no defrost cycle.	
Range		Example : If P7 is set to 15 Mins and P8 parameter is set to 1 Hr. then after every 1 Hr defrosting will take place for 15 mins.	
Min	Max		
0 Min	99 Min		
07	P8 Parameter	Function : To set defrost frequency.	
To change the P8 parameter, press the set key.		Use UP/DOWN keys to set desired value. This is the amount of time between two defrost cycles.	
Range		Example : same as P7 parameter.	
Min	Max		
1 Hr	31 Hrs		
08	P9 Parameter	Function : To set power on defrost delay.	
To change the P9 parameter, press the set key.		Use UP/DOWN keys to set desired value. This is the amount of time at power on after which defrosting will take place once.	
Range		If this parameter is set to 0, there will be no power ON defrost.	
Min	Max		
0 Min	99 Min		
		Example : If P9 parameter is 30 mins then at power after 30 mins defrosting will take place once.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
09	P10 Parameter	Function : To set type of defrost.	
To change the P10 Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		HTR : Heater defrost where compressor is OFF.	
Min	Max	Fact. Set	
HTR	HTG	HTR	
10	P11 Parameter	Function : To set drip time for defrost.	
To change the P11 Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		During this period Compressor, Evaporator Fan, LSV relay and Heater will stay OFF so that the defrost water can drain out.	
Min	Max	Fact. Set	
0 Min	30 Min	1 Min	
11	P12 Parameter	Function : To set type of computation for defrost time..	
To change the P12 Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		REAL = Total of real time.	
Min	Max	Fact. Set	
REAL	CRH	REAL	
		Example : This means that the time calculation for defrost frequency will be for the total hours the unit has been running. CRH - Sum of total compressor operating times. This means that for time calculation, the unit will add the total time the compressor has been in an ON mode. It keeps a record of the hours worked +/-½ Hour incase of a power failure. Example : If Defrost frequency is set to 6hrs. and 3.45 hrs have passed after unit has started and power fails, then defrost cycle will stat after 3½ hours when power resumes.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
12	P13 Parameter	Function : To set defrost stop temperature	
To change the P13 Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		If coil/Evap temperature is reached upto this temperature defrost will stop.	
Min	Max	Fact. Set	
-40.0°C	50.0°C	4.0°C	
		Example : If this parameter is set to 4.0°C, then if defrosting is in progress then when temperature reaches 4.0°C, the defrost process will stop.	
13	DI-D Parameter	Function : To select AUX or compressor thermal trip digital I/P	
To change the DI-D Parameter , press the set key.		Use UP/DOWN keys to set desired value.	
Range		If Selected as "AUX" then at fault it will display "AUX" on display.	
Min	Max	Fact. Set	
AUX	CTH	CTH	
		If Selected as "CTH" then at fault it will display "CTH".	
14	OPS Parameter	Function : To Enable / Disable OPS I/P.	
To change the OPS Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		ENB : OPS I/P is enabled.	
Min	Max	Fact. Set	
DIS	ENB	ENB	
		DIS : OPS I/P is disabled.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
15	QFD Parameter	Function : To set quick freeze duration.	
To change the QFD Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This is the maximum amount of time allowed for Quick Freeze. If set to "0", there will be no quick freeze.	
Min	Max	Fact. Set	
0 Hr	12 Hrs	2 Hr	
		Example : If QFS is set to -20.0°C, and quick freeze duration is set to 1 hr ,then when it is in quick freeze mode, then the Comp. will work on -20.0°C set point for 1hr.	
16	CND6 Parameter	Function : To set condenser ON delay timings.	
To change the CND6 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		When Compressor delay over Condenser Fan will come ON first, after cond. On delay over Comp will come ON.	
Min	Max	Fact. Set	
0 Sec	30 Sec	15 Sec	
17	CND7 Parameter	Function : To set condenser status at hot gas defrost.	
To change the CND7 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This function is used to decide the condenser status when hot gas defrost is ON. This parameter is not applicable for Heater defrost.	
Min	Max	Fact. Set	
OFF	ON	OFF	
		At hot gas defrost, OFF : Condenser will be OFF ON : Condenser will be ON	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
18	L1 Parameter	Function : To set Evaporator Fan stop temperature.	
To change the L1 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This setting is used to limit the Max. temperature beyond which the Evap.Fan will cut off.	
Min	Max	Fact. Set	
-40.0°C	50.0°C	2.0°C	
		Example : If this parameter is set to 2.0°C, then Evap. Fan will cut OFF at 2.0°C.	
19	L2 Parameter	Function : To set Evaporator Restart Delay.	
To change the L2 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		Once the fan get OFF at L1 condition, it will not get restart until L2 duration is over.	
Min	Max	Fact. Set	
0 Min	20 Min	1 Min	
		Example : If this is set at 1 minutes, Evap. Fan relay will cut off at the set by Evap. Fan Stop TC. Parameter but the Fan will not come on for a minimum of 1 minutes even if it's differential is achieved earlier.	
20	L3 Parameter	Function : To set Evaporator Fan status at compressor off.	
To change the L3 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		OFF : Evaporator Fan will be OFF at compressor OFF.	
Min	Max	Fact. Set	
OFF	ON	ON	
		ON : Evaporator Fan will be ON at compressor OFF.	
21	L4 Parameter	Function : To set Evaporator Fan differential.	
To change the L4 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		Example : If L1parameter is set to 2.0°C, and if Evaporator Fan differential parameter is set to 2.0°C,then Evap. Fan will cut off at 2.0°C and restart only at 0.0°C.	
Min	Max	Fact. Set	
0.5°C	20.0°C	2.0°C	
		(2.0°C-2.0°C = 0.0°C) (L1 - L4)	

Description of parameters and functions.				
Sr. No.	Parameter		Parameter setting method	
22	L5 Parameter		Function : To set Evaporator probe calibration.	
	To change the L5 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		In time it may be possible that the display may be offset by a degree or so. To compensate for this error, you may need to add or minus the degrees required to achieve the correct temperature. Setting value is from -10.0°C to + 10.0°C.	
	Min	Max	Fact. Set	
	-10.0°C	10.0°C	0.0°C	
23	L7 Parameter		Function : To set Compressor-Evaporator Fan status at Door open condition.	
	To change the L7 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		At Door Open, NORM : Normal.	
	Min	Max	Fact. Set	FAN : Evaporator Fan OFF. COMP : Compressor OFF. F-C : Compressor and Evaporator Fan OFF.
	NORM	F-C	NORM	
24	L8 Parameter		Function : To set Evaporator Fan status during defrost.	
	To change the L8 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		OFF : Evaporator Fan OFF during defrost.	
	Min	Max	Fact. Set	ON : Evaporator Fan ON during defrost.
	OFF	ON	OFF	
25	BUZ Parameter		Function : To enable / disable buzzer.	
	To change the BUZ parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		Example: ENB : Buzzer enabled.	
	Min	Max	Fact. Set	DIS : Buzzer disabled.
	DIS	ENB	ENB	

Description of parameters and functions.				
Sr. No.	Parameter		Parameter setting method	
26	AL Parameter		Function : This parameter is used to Enable / Disable alarm relay.	
	To change the AL Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		DIS : To deactivate Alarm Relay in fault condition.	
	Min	Max	Fact. Set	ENB : To activate Alarm Relay in fault condition.
	DIS	ENB	ENB	
27	ADT Parameter		Function : This parameter is used to set HT power on delay for alarm.	
	To change the ADT parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		Example : If you set this parameter to 20, once the power is switched on, the HT alarm will not activate for 20 minutes after the power is switched on. This is most useful to avoid the nuisance alarms when the ambients are high when the machine is switched on after a long time.	
	Min	Max	Fact. Set	
	0 Min	99 Min	30 Min	
28	ADD Parameter		Function : This parameter is used for time delay to activate Alarm/Buzzer relay at Door Open.	
	To change the ADD parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		Example : This Parameter is set to 60 Sec & Door is open then Alarm/Buzzer will be ON after 60sec, if AL & BUZ parameters are enabled.	
	Min	Max	Fact. Set	
	0 sec	600 sec	60 sec	
29	THD Parameter		Function : This parameter is used to set duration for temperature hold at door open.	
	To change the THD parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		Example : This Parameter is set to 60sec, Room Temperature is -18.0°C & Door open condition occurs then Room Temp value -18.0°C at Door open condition will be hold for the 60sec, if Room Temperature is	
	Min	Max	Fact. Set	
	0 sec	180 sec	0 sec	

Description of parameters and functions.			
Sr. No.	Parameter		Parameter setting method
			increasing. After over the Temperature hold duration display temperature will be increased by 0.1°C at every sec until it reaches current Room Temperature.
30	C-UL Parameter		Function : Under load limit for compressor current.
To change the C-UL parameter, press the set key.			Use UP/DOWN keys to set desired value.
Range			Example : If C-UL= 1.0A and compressor current is less than 1.0A then and exists till C2 current sensing delay then it is registered as UL fault. Compressor will get OFF on this fault. If after 3 retries within 1 Hour current drawn is still less than 1.0Amp the controller will trip the compressor on fault and activate respective alarm relay. Also display will flash 'C-UL'. Controller will go in manual reset mode.
Min	Max	Fact. Set	
0.0A	(C-OL -1.0)A	1.0A	
31	C-OL Parameter		Function : Over load limit for compressor current.
To change the C-OL parameter, press the set key.			Use UP/DOWN keys to set desired value.
Controller with 20A CT			Example : If C-OL= 15.0 A and compressor current is greater than 15.0 A then and exist till C2 current sensing delay then C-OL fault exists and flash on display. Compressor will be tripped on this fault.
Range			
Min	Max	Fact. Set	
(C-UL +1.0) A	20.0A	15.0A	
Controller with 50A CT			NOTE: 20/50A CT option available while ordering controller.
Range			
Min	Max	Fact. Set	
(C-UL +1.0) A	50.0A	30.0A	

Description of parameters and functions.			
Sr. No.	Parameter		Parameter setting method
32	C2 Parameter		Function : Current sensing time delay.
To change the C2 parameter, press the set key.			Use UP/DOWN keys to set desired value.
Range			Example : If C2 = 5 sec then, any current fault will be valid only when it exists for more than 5 sec.
Min	Max	Fact. Set	
5 Sec	120 Sec	5 Sec	
33	D0 Parameter		Function : To enable or Disable HP sensing.
To change the D0 parameter, press the set key.			Use UP/DOWN keys to set desired value.
Range			Example : If this parameter is set to ENB : HP sensing is enabled. DIS : HP sensing is disabled. Setting this parameter to disable will ignore HP fault for compressor. If this parameter is set to Enable then controller will detect HP trip.
Min	Max	Fact. Set	
DIS	ENB	ENB	
34	D1 Parameter		Function : To enable or disable LP sensing.
To change D1parameter, press the set key.			Use UP/DOWN keys to set desired value.
Range			Example: If this parameter is set to ENB : LP sensing is enabled. DIS : LP sensing is disabled. Setting this parameter to disable will ignore LP fault for compressor. If this parameter is set to Enable then controller will detect LP trip.
Min	Max	Fact. Set	
DIS	ENB	ENB	

Description of parameters and functions.				
Sr. No.	Parameter		Parameter setting method	
35	D2 Parameter		Function : Fault sensing logic.	
To change D2 parameter, press the set key.			Use UP/DOWN keys to set desired value.	
Range			0V : 0V at HP/LP/AUX input will be sensed as fault and trip the compressor.	
Min	Max	Fact. Set	230V : 230V at HP/LP/AUX input will be sensed as fault and trip the compressor.	
0V	230V	0V		
36	D3 Parameter		Function : To set LP sensing delay.	
To change D3 parameter, press the set key.			Use UP/DOWN keys to set desired value.	
Range			Example : If this parameter is set to 5 sec, then LP fault will be sensed only when it present continuously for 5 Secs.	
Min	Max	Fact. Set		
0 Sec	180 Sec	30 Sec		
37	D4 Parameter		Function : To set reset mode for HP fault.	
To change D4 parameter, press the set key.			Use UP/DOWN keys to set desired value.	
Range			MAN : Manual Mode.	
Min	Max	Fact. Set	AUTO : Auto mode.	
MAN	AUTO	AUTO	If this parameter set to "MAN" mode HP fault will be cleared only after pressing reset key for 2 seconds.	
			If this parameter is set to "AUTO" mode HP fault will be cleared automatically when it is healthy.	



Description of parameters and functions.				
Sr. No.	Parameter		Parameter setting method	
38	E1 Parameter		Function : To set Compressor Relay status on Probe Failure.	
To change E1 parameter, press the set key.			Use UP/DOWN keys to set desired value.	
Range			When set to	
Min	Max	Fact. Set	ON : Relay will stay ON.	
ON	OFF	CYC	CYC : Relay performs a duty cycle of as per TON & TOFF .	
			OFF : Relay will stay OFF.	
39	TON Parameter		Function : To set ON cycle time for compressor at room probe fail.	
To change TON parameter, press the set key.			Use UP/DOWN keys to set desired value.	
Range			At room probe fail condition when E1 parameter is selected as 'CYC' then the ON cycle is specified by TON parameter.	
Min	Max	Fact. Set		
1 Min	30 Min	10 Min		
40	TOFF Parameter		Function : To set OFF cycle time for compressor at room probe fail.	
To change TOFF parameter, press the set key.			Use UP/DOWN keys to set desired value.	
Range			At room probe fail condition when E1 parameter is selected as 'CYC' then the OFF cycle is specified by TOFF parameter.	
Min	Max	Fact. Set		
1 Min	30 Min	4 Min		
41	E7 Parameter		Function : To set Display at defrosting.	
To change E7 parameter, press the SET key.			Use UP/DOWN keys to set desired value.	
Range			TEMP : During defrost, temperature will be displayed.	
Min	Max	Fact. Set	DEFR : During defrost, 'Defrost ON' will scroll.	
TEMP	DEFR	TEMP		

Description of parameters and functions.				
Sr. No.	Parameter		Parameter setting method	
42	E8 Parameter		Function : Defrost duration during Coil probe failure.	
To change E8 parameter, press the SET key.			Use UP/DOWN keys to set desired value.	
Range			Example: If this is set to 10 min, then manual defrost for 10 min will take place during Coil probe fail.	
Min	Max	Fact. Set		
1 Min	15 Min	5 Min		
43	LD Parameter		Function : To set time delay to switch off the light .	
To change LD parameter, press the SET key.			Use UP/DOWN keys to set desired value.	
Range			This parameter is used set the time delay to automatically switch OFF the light. If LD is set to 0 then this parameter is disabled.	
Min	Max	Fact. Set	Example : If this parameter is set to 7 mins then, when light is switched ON, after 7 mins it will be switch OFF automatically.	
0 Min	30 Min	7 Min		
44	LSD Parameter		Function : This parameter is used to enable / disable light relay ON at door open.	
To change LSD parameter, press the SET key.			Use UP/DOWN keys to set desired value.	
Range			If this parameter is set to Enable then whenever Door get open, the Light Relay will be ON.	
Min	Max	Fact. Set	If this parameter is set to Disable then Light Relay will be ON/OFF functioning manually and as per LD parameter.	
DIS	ENB	ENB		
45	PDN Parameter		Function : To activate Solenoid Valve relay.	
To change PDN parameter, press the set key.			Use UP/DOWN keys to set desired value.	
Range				
Min	Max	Fact. Set		
DIS	EDEF	DIS		

Cont.

Cont.

Description of parameters and functions.				
Sr. No.	Parameter		Parameter setting method	
			DIS : Pump down disable and SV relay will active only with Compressor except Hotgas defrost. ETMP : Pump down enable at Set point when compressor tripped on Set Point. EDEF : Pump down enable at Set point when heater defrost condition occurs. Example : ETMP : If this parameter is set to ETMP then SV relay will be ON/FF & pump down at Set point. EDEF : If this parameter is set to EDEF then SV relay will be ON/OFF on SP & pump down only at heater defrost condition.	
46	PW Parameter		Function : To change password.	
To change the PW parameter, press the set key.			Use UP/DOWN key to change the password.	
Range			User can enter into program mode only if correct password is entered. If the password is wrong it will show 'INVALID PASSWORD'.	
Min	Max	Fact. Set		
0	9999	0		
47	CRH Parameter		Function : To view Compressor run Hours.	
			It will display compressor run hours. It's a read only parameter.	
48	CCRH		Function : Clear Compressor Run Hours.	
Range			If this parameter is set to 'YES' compressor run hours (CRH) are cleared.	
Min	Max	Fact. Set		
NO	YES	NO		

Description of parameters and functions.			
Sr. No.	Parameter		Parameter setting method
49	ID Parameter		Function : To set Device ID.
To change Device ID parameter, press the SET key.			This parameter is used to set the Device ID for the controller.
Range			
Min	Max	Fact. Set	
1	240	-	
50	LP Parameter		Function : To activate Keypad Lock.
To change Keypad Lock parameter, press the set key.			This parameter can lock the keypad so that tempering is not possible by by-standers.
Range			
Min	Max	Fact. Set	
NO	YES	NO	
			NO : deactivates keypad lock. YES : activates keypad lock.
			On activation, all the parameters can only be viewed, but not modified. If the keypad is locked "LOCK" message will be displayed..
51	PO Parameter		Function : To enable/disable Power Switch.
To change PO parameter, press the SET key.			Use UP/DOWN keys to get desired value & press SET key to confirm. DIS : Disable power switch ENB : Enables power switch Controller has power switch, which if enable puts controller in active or stand by state. If  key press for 2 seconds controller will go in stand by mode, display will be as per "PDIS" parameter. To again switch to ACTIVE WORKING MODE, press power switch again for 2 seconds. All leds and display will flash and enter into NORMAL WORKING MODE.
Range			
Min	Max	Fact. Set	
DIS	ENB	DIS	
			

Description of parameters and functions.			
Sr. No.	Parameter		Parameter setting method
52	PDIS Parameter		Function : To set display at power OFF mode.
	To change PDIS parameter, press the SET key.		Use UP/DOWN keys to set desired value.
	Range		At power OFF mode power OFF LED will glow & display will be as below,
	Min	Max	Fact. Set
	LED	TEMP	LED
			LED : Display Will be Blank. OFF : Display will show OFF. TEMP : Display will show Temperature.
53	FS Parameter		Function : To restore default settings of the controller.
	To change FS parameter, press the SET key.		Use UP/DOWN keys to set desired value.
	Range		When set to YES all parameters are programmed to factory values. Useful to debug setting related problems.
	Min	Max	Fact. Set
	NO	YES	NO
54	EP Parameter		Function: To exit from program mode.
	To exit programming parameter, press the SET key.		Once the set key is pressed, the controller goes into the normal mode and displays the Room Temperature and all settings are recorded.

Technical Data

Housing	: Plastic / Sheet Metal (as per customer requirement)
Dimensions	: Plastic : (H)400 x (W) 300 x (D)135 mm : Sheet Metal : (H)450 x (W) 400 x (D)200 mm
Mounting	: Wall mounting.
Controller	: CRC-2052
Connection	: Spring clamp terminal block. 4 sq. mm wire.
Display	: 4 Digit, 1" Dot matrix Display and 13 LEDs for indication.
Data Storage	: Non-Volatile EEPROM Memory.
Power Input (Options)	: 415Vac +/-10%, 50-60Hz. 3Phase Supply with Neutral
Operating Temp	: 5°C to 50°C(non-condensing).
Storage temp	: -20°C to 70°C(non-condensing).
Output	:
Compressor Relay	: 5A/230vac
Defrost Relay	: 5A/230vac
Evap. Relay	: 5A/230vac
Condenser Relay	: 10A/230vac
Light Relay	: 5A/230vac
Alarm Relay	: 5A/230vac
LSV Relay	: 10A/230vac
Sensors :	
1) Temperature sensor:	
Sensor Type	: NTC Thermistor.
Resolution	: 0.1°C.
Accuracy	: +/-1°C.
Probe Tolerance at 25°C	: +/-0.3°C.
Room & Evap Temperature :	
Range	: -50.0°C to 50.0°C
Analog I/p:	
Compressor current (R,Y,B)	
Resolution	: 0.1Amp.
Accuracy	: +/-1 Amp.
Digital Inputs:	
HP, LP, Auxiliary / CTH(Compressor Thermal) , Oil Pressure Switch(OPS), Door, SPPR, R-Ph, Y-Ph, B- Ph.	
Buzzer	: Internal
RS485 Connectivity	: Modbus RTU Protocol Baud Rate : 9600 Device ID : 1 (By Default)

Instruction Manual

LVM (Line Voltage Monitor) Three Phase VMRC-10/3

Index


PARAMETER	DESCRIPTION	Pg. No.
	Introduction	29
	Get to know your Controller.	29
	To set program mode.	30
<i>rEF</i>	To set Reference Voltage.	30
<i>oU</i>	To set Over voltage Limits.	30
<i>uU</i>	To set Undervoltage Limits.	31
<i>unb</i>	To set Un Balance Value.	31
<i>ttd</i>	To set Time Delay.	31
<i>tdr</i>	To set fault recover delay.	32
<i>CrY</i>	To set Calibration of Voltage.	32
<i>CrYb</i>	To set Calibration of Voltage.	32
<i>Crb</i>	To set Calibration of Voltage.	33
<i>dSP</i>	To set Display mode.	33
<i>FS</i>	To Restore factory defaults.	33
<i>End</i>	End programming.	34
	Technical Data.	35
	Front View & Connection Diagram.	35


Introduction

VMRC-10/3 is three phase Line voltage monitor (LVM) used to protect device from Single Phasing, voltage unbalance, phase reversal and under/over voltage. It shows real time voltages between phase and neutral.

There is an Output of alarm relay is given to the controller as SPPR input. Features are easily understood by examples in the instruction below.

Get to Know Your Controller



Description of parameters and functions.		
Sr. No.	Parameter	Parameter setting method
To set other parameter		
Press & hold PRG key for 4 seconds 		Display will show 'rEF' and scroll the description of the parameter. To go to other parameters, use up / down keys.
01	<i>rEF</i> PARAMETER	Function : To set Reference voltage.
To change the rEF Parameter, press the set key.		Use UP/DOWN keys to set desired value. Base reference voltage to calculate under voltage and over voltage values.
Range		
Min	Max	Fact. Set
381V	415V	415V
		Min and Max value will change according to display type for settings. Example : If dsP is L-L then Min= 381V, Max= 415V.
02	<i>oV</i> PARAMETER	Function : To set Overvoltage Limits.
To change the oV parameter, press the set key.		Use UP/DOWN keys to set desired value. If the a/c voltages goes above this limit will trip respective a/c on Overvoltage("Ov") fault.
Range		
Min	Max	Fact. Set
5V	75V	35V
		Example : Over voltage is calculated depending on Reference voltage + Ov value. i.e, Ov Set Point = Ref + Ov , When controller trip on Ov Fault it will recover when input voltage fall below (Ref - (Ov /2).

Description of parameters and functions.		
Sr. No.	Parameter	Parameter setting method
03	<i>uV</i> PARAMETER	Function : To set Undervoltage Limits.
To change the uV parameter, press the set key.		Use UP/DOWN keys to set desired value. If the a/c voltages goes below this limit will trip respective a/c on undervoltage("Uv") fault.
Range		
Min	Max	Fact. Set
5V	75V	35V
		Example : Under voltage is calculated depending on Reference voltage - Uv value. i.e Uv Set Point = Ref - Uv , When controller trip on Uv Fault it will recover when input voltage above (Ref – (Uv /2).
04	<i>unb</i> PARAMETER	Function : To set Un Balance value.
To change the unb parameter, press the set key.		Use UP/DOWN keys to set desired value.
Range		
Min	Max	Fact. Set
10V	120V	60V
		Unbalance fault raised when voltage difference between any of two phases goes above Unb value and recovers when the difference is less than (UNB/2).
05	<i>ttd</i> PARAMETER	Function : To set time delay.
To change the ttd parameter, press the set key.		Use UP/DOWN keys to set desired value.
Range		
Min	Max	Fact. Set
0Sec	60Sec	10Sec
		Time delay provided to avoid false triggering, when any fault last more than TTD value then only fault is raised and this fault is applicable to Under voltage, Over voltage and Unbalance fault.(i.e., In case of Phase Loss or Phase sequence fault alarm will come immediately).

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
06	<i>t_{dr}</i> PARAMETER	Function : To set fault recover delay.	
To change the tdr parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		Time delay provided to add delay in fault recover time, to avoid sudden fault triggering and reset.	
Min	Max	Fact. Set	
0Sec	240Sec	10Sec	
07	<i>C_{rY}</i> PARAMETER	Function : To set calibration of voltage for r-y or r-n phase.	
To change the CrY Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for r-y. When dsP is L-n then it sets calibration for r-n.	
08	<i>C_{yb}</i> PARAMETER	Function : To set calibration of voltage for y-b or y-n phase.	
To change the Cyb parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for y-b. When dsP is L-n then it sets calibration for y-n.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
09	<i>C_{rb}</i> PARAMETER	Function : To set calibration of voltage for r-b or b-n phase.	
To change the Crb parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for r-b. When dsP is L-n then it sets calibration for b-n.	
10	<i>d_{SP}</i> PARAMETER	Function : To set view display mode.	
To change the dsP parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		There are two type of display output, Line to Line Voltage (L-L) and Line to Neutral (L-n), Depending on this parameter REF parameter also changes.	
Min	Max	Fact. Set	
L-L	L-n	L-L	
11	<i>F_S</i> PARAMETER	Function : To restore the default settings of the controller.	
To change the FS parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		When set to 1, all parameters are programmed to factory values.	
Min	Max	Fact. Set	
nO	YES	nO	

Description of parameters and functions.		
Sr. No.	Parameter	Parameter setting method
12	End PARAMETER	Function :To end programming.
To change the end parameter, press the set key.		Once the set key is pressed, the controller goes into the normal mode and displays the voltage readings.

Technical Data

Main Functions : Voltage Monitoring.

Phase Sequence Monitoring.

Phase Loss and Phase Unbalance detection.

Uv and Ov Detection.

Settable Uv and Ov Parameter.

Dimensions : Front : 70mm X 45mm,
Depth : 72.3 mm

Input : R, Y, B Phases and Neutral Input.

Output : Alarm Relay : 5A Resistive.

Application :Voltage and phase sequence monitoring and controlling.
Under voltage and Over voltage detection.


General Specification :


Input Voltage Range from 100VAC to 265VAC.

Mounting : Din rail mounting.

Connections : Screw terminals : $\leq 2.5\text{sqmm}$ one wire/terminal only.

**Front View & Connetion Diagram for
Three Phase Voltage Monitor (VMRC- 10/3)**





1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	
MAIN INCOMING SUPPLY				ROOM PROBE		COIL PROBE		+ -		COMPRESSOR		EVAPORATOR		DEFROST		CONDENSER		LSV		LIGHT		ALARM		FRAME HEATER		CCH		OIL PRESSURE SWITCH		AUX. / CTH		HP / LP OUT		HP IN		LP IN		GND ↓ IN ↑			
R	Y	B	N							R	Y	B	R	Y	B	N	R	Y	B	L	N	L	N	C	NO	C	NO	L	N	L	N	OUT	IN	OUT	IN						
SUGGESTED CONNECTOR STICKER																																									

SUGGESTED CONNECTOR STICKER

Controller

Controller should be installed in a place protected by vibration, water and corrosive gasses and where ambient temperature does not exceed the values specified in the technical data.

Probe

To give a correct reading, the probe must be installed in a place protected from thermal influences, which may affect the temperature to be controlled.

Caution

WIRING : The probe and its corresponding wires should never be installed in a conduit next to control or power supply lines. The electrical wiring should be done as shown in the diagram. The power supply circuit should be connected to a protection switch.

WARNING : Improper wiring may cause irreparable damage and personal injury. Kindly ensure that wiring is done by qualified personnel only.

Maintenance : Cleaning : Clean the surface of the controller with a soft moist cloth. Do not use abrasive detergents, petrol, alcohol or solvents.

Notice

The information in this document is subject to change in order to improve reliability, design or function without prior notice and does not represent a commitment on the part of the company. In no event will the company be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company.

Disclaimer

This manual & its contents remain the sole property of PVR Controls, India and shall not be reproduced or distributed without authorization. Although great care has been taken in the preparations of this document, the company or its vendors in no event will be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company. PVR Controls, reserves the right to make and changes or improvements without prior notice.

Warranty

This product is warranted against defects in materials and workmanship for a period of one year from the date of purchase. During the warranty period, product determined by us to be defective in form or function will be repaired or, at our option, replaced at no charge. This warranty does not apply if the product has been damaged by accident, abuse, and misuse or as a result of service or modification other than by the company. This warranty is in lieu of any other warranty expressed or implied. In no event shall the company be held liable for incidental or consequential damages, such as lost revenue or lost business opportunity arising from the purchase of this product.

OUR OTHER PRODUCTS



INDIA

Cold Room Controller

Chiller Controller

Two Compressors Controller

Heating Controller

Humidity Controller

Pressure Controller



Ball Valves

Globe Valves

Hand Valves

Flow Switches

Solenoid Valves