


User Manual



www.pvrcontrols.com

**NANOCHILL
NC-120A**



Introduction

The Subzero "NANO CHILL"(NC 120) are controllers that integrates all the basic control functions required by a chiller. A user friendly Lcd screen displays all parameters, status and alarm messages.

Features:

- ◆ LCD with backlight to display all parameters.
- ◆ 3 NTC probes for Liquid temp, Antifreeze temperature, Condensor Temperature.
- ◆ Range : - 30.0°C to + 50.0°C
- ◆ Resolution 0.1°C
- ◆ Relay outputs : Compressor , Precision SV, Condensor, Pump, Alarm & Water SV,
- ◆ HP,LP, Compressor O/L, SPP, Pump O/L, Auxiliary Fault trip protection for Compressor and pump
- ◆ Auto/Manual reset for HP, LP and AFT.
- ◆ Compressor current sensing upto 20Amp.
- ◆ It also protect compressor by tripping it in underload & overload conditions.

Items included :

NO.	ITEMS	QTY
1.	CONTROLLER	1No.
2.	TRANSFORMER	1No.
3.	SIDE LOCK (BIG)	2Nos.
4.	CATALOG	1No.
5.	PROKEY	1No.
6.	SENSORS	3Nos.

Optional :

NO.	ITEMS	QTY
1.	LIQUID LEVEL SWITCH	1Nos.
2.	CT WITH WIRE HARNESS	1 Set

INDEX

PARAMETER	DESCRIPTION	Pg. No.
SET MODE		
CHILLER SET TEMP.	To set the cutout point of the Controller.	06
To set other parameters	PROGRAM MODE	06
CHILLER SET TEMP.	To set Chiller Set point	06
COMP TIME DELAY.	To set compressor restart delay.	06-07
DIFFERENTIAL	To set temperature differential for compressor restart.	07
HIGH TEMP. ALARM	To set maximum allowable high temperature limit & alarm.	07
LOW TEMP. ALARM	To set minimum allowable low temperature limit and alarm..	08
AFT PROBE STATUS	To enable or disable Antifreeze function.	08
AFT SET TEMP.	To set Antifreeze set point.	08
AFT DIFFERENTIAL	To set Antifreeze differential	09
LIQ. PROBE CAL.	To set Main(Liquid) probe calibration.	09
AFT PROBE CAL.	To set Antifreeze probe calibration.	09
COND PROBE CAL.	To set Condenser probe calibration .	10
CURRENT CAL	To set Current calibration.	10
HT POWER ON DLY	This sets Power ON delay for high temperature alarm to avoid false alarms.	10
COND PROBE ACTIVE	To enable or disable condenser probe.	10
COND SET TEMP.	To set Condenser set temperature.	11
COND. SET DIFF.	To set differential for Condenser.	11

INDEX

PARAMETER	DESCRIPTION	Pg. No.
FAULT SENS LOGIC	To set tripping voltage of digital inputs.	11
FAULT IN STAND BY	This decides whether controller should display faults in stand by mode or not.	12
LP SENSING DLY	To set LP fault sensing delay	12
HP/AFT RESET	To set HP and AFT fault to Auto or Manual reset.	12
LP FAULT RESET	To set LP fault to Auto or Manual reset.	13
LIQ. LEVEL SENSOR	Enable / disables liquid level sensing .	13
PUMP RUN LOGIC	This parameter configures pump working logic	13
COND RUN LOGIC	This parameter configures condenser working logic.	14
COND START DLY	This parameter set the time delay that condenser should start before compressor.	14
CURRENT INPUT	To enable / Disable Current Sensing	14
CURRENT LO LIMIT	Lower current limit for the compressor .	15
CURRENT HI LIMIT	Higher current limit for the compressor	15
CURRENT RETRIALS	No. of retrials before sensing underload / overload fault in auto mode	15
CURRENT FAULT RST	To set Ct faults auto or manual reset.	15
CONFIG AUX I/P	This configures AUX i/p as EWFS fault or as AUX i/p to switch off whole system.	16
EWFS SATRTUP DLY	It sets power on delay for EWFS fault sensing.	16
EWFS NORMAL DLY	It sets normal delay for EWFS fault sensing.This avoids false tripping due to water splashing.	16


INDEX

PARAMETER	DESCRIPTION	Pg. No.
AUX I/P SETTING	This parameter will set pump working incase of Auxilliary fault.	17
PRECISION MODE	To enable / disable controller function in precision mode.	17
AUTOSTART	To enable auto start of controller at power ON.	17
KEYPAD LOCK	To lock Keypad.	17
CLEAR FAULT LOG	To clear last fault history.	18
FACTORY DEFAULTS	Revert to Factory set parameters.	18
COMP RUN HRS	To display total compressor working Hours.	18
PUMP RUN HRS	To display total pump working Hours.	18
CLR COMP RUN HRS	To clear comp run hrs.	18
CLR PUMP RUN HRS	To clear pump run hrs.	19
ENTER YOUR NAME	To set customer name to be displayed at controller power ON.	19
ENTER YOUR NO.	To set customer service number.	19
SET - EXIT UP/DOWN - SCROLL	Once the SET key is pressed the control goes into the normal mode and displays the temperature.	19
	Key Functions	20
	Technical Data	21
	Suggested Wiring Diagram	22
	Panel Cutout & Dimensions	23

Parameter List

Min: MINIMUM Max : MAXIMUM
Fact. Set : FACTORY SETTING(DEFAULT)

Description of parameters and functions.

Sr.No.	Parameter (LCD Message)	Parameter setting method.
SET MODE		
01	CHILLER SET TEMP.	Function : To set Chiller Set point.
	Press and hold "SET" key for 2 seconds and Release.	Lcd will change to set mode and flash. Then press set key once & release .Set point will flash. Set point can now be changed by using UP/DOWN key. After achieving the desired range, press the SET key .
Range		
Min	Max	Fact. Set
Lt +0.1°C	Ht -0.1°C	10.0°C
		Lt°C = Low temp Limit. Ht°C = High temp.Limit
PROGRAM MODE		
02	To set other parameters.	LCD will show Program Mode. And the set Temperature To go to other parameters, use up/ down keys.
	Hold  key for 2 seconds and release.	
03	CHILLER SET TEMP.	Function : To set Chiller Set point.
	To change Set Temp parameter, press the set key.	First set key once & release Parameter value will flash. Now Use UP/DOWN keys to set desired value.
Range		
Min	Max	Fact. Set
Lt +0.1°C	Ht -0.1°C	10.0°C
04	COMP. TIME DELAY	Function : To set compressor restart delay.
	To change Comp Time Delay parameter,press the set key.	Use UP/DOWN keys to set desired value.

Contd.

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
Range			EXAMPLE: If this parameter is set at 3 minutes, the compressor will cut off at the set temperature, but will not restart for a minimum of 3 minutes. This time delay is also effective at 'Power On' of the system. This safety feature is used to protect the compressor from restarting within a short period due to power fluctuations.
Min	Max	Fact. Set	
0 Min	20 Min	3 Min	
05	DIFFERENTIAL	Function: To set temperature differential for compressor restart.	
To change DIFFERENTIAL parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			EXAMPLE: If the set point is set at 10.0°C and differential is set as 2.0°C, then when the system reaches 10°C, the compressor will cutout. Since differential is 2.0°C, the compressor will cut in (restart) at 12.0°C (10.0°C + 2.0°C).
Min	Max	Fact. Set	
0.1°C	10.0°C	2.0°C	
06	HIGH TEMP. ALARM	Function: To set maximum allowable high temperature limit and alarm.	
To change High Temp parameter, press the set key.		First Press set key once & release Parameter value will flash. Now UP / DOWN keys to set desired value.	
Range			EXAMPLE : If this parameter is set to 50.0°C, then once chiller temperature goes above 50.0°C then controller will show "Ht" and alarm will be ON.
Min	Max	Fact. Set	
Set Point -1	50.0°C	50.0°C	

07

NC-120A

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
07	LOW TEMP. ALARM	Function: To set minimum allowable low temperature limit and alarm.	
To change the Low Temp parameter, press the set key.		First Press set key once & release Parameter value will flash. Now UP / DOWN keys to set desired range.	
Range			EXAMPLE: Setting this parameter at 5.0°C will not allow the set point to go below 5.0°C Also, if the temperature reaches or goes below 5.0°C the display will show Low Temp. Alarm and at this point the alarm will activate.
Min	Max	Fact. Set	
AFT Set Temp. +0.1°C	Set Temp. -0.1	5.0°C	
08	AFT PROBE STATUS	Function : To enable or disable Antifreeze function.	
To change AFT PROBE STATUS parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			Disable = It disables the Antifreeze Trip function of the controller Enable = It enables the Antifreeze Trip function of the controller
Min	Max	Fact. Set	
Disable	Enable	Disable	
09	AFT SET TEMP	Function: To set Antifreeze tripping point.	
To change AFT SET TEMP. parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			EXAMPLE: If this parameter is set to 5.0°C controller will trip the compressor on Antifreeze fault if the AFT sensor goes below 5.0°C.
Min	Max	Fact. Set	
-30.0°C	Lt-0.1°C	4.0°C	

NC-120A

08

Description of parameters and functions.										
Sr.No.	Parameter (LCD Message)	Parameter setting method.								
10	AFT DIFFERENTIAL	Function : To set fault resetting differential once it tripped of Aft set point.								
	To change the AFT Differential parameter, press the set key.		Use UP/DOWN keys to set desired value.							
	Range <table border="1"> <thead> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>1.0°C</td> <td>10.0°C</td> <td>2.0°C</td> </tr> </tbody> </table>			Min	Max	Fact. Set	1.0°C	10.0°C	2.0°C	EXAMPLE : If the AFT set point is set at 5.0°C and differential is set to 2.0°C then after tripping on AFT fault controller will clear the AFT fault only when the AFT Temperature goes above 7.0°C(5.0°C+2.0°C).
	Min	Max	Fact. Set							
1.0°C	10.0°C	2.0°C								
11	LIQ. PROBE CAL.	Function : To set Main(Liquid) probe calibration.								
	To change Main Probe Cal. parameter, press the set key.		Use UP/DOWN keys to set desired range. During the course of time there may be a slight offset in the actual temperature and the temperature displayed.							
	Range <table border="1"> <thead> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>-10.0°C</td> <td>10.0°C</td> <td>0.0°C</td> </tr> </tbody> </table>			Min	Max	Fact. Set	-10.0°C	10.0°C	0.0°C	EXAMPLE : If the actual temperature is 20.0°C and the temperature on the controller shows 22.0°C set this parameter to -2.0°C and once out of this mode, the temperature will display 20.0°C. (22.0°C-2.0°C).
	Min	Max	Fact. Set							
-10.0°C	10.0°C	0.0°C								
12	AFT PROBE CAL	Function : To set Antifreeze probe calibration.								
	To change AFT Probe Cal. parameter, press the set key.		Use UP/DOWN keys to set desired value.							
	Range <table border="1"> <thead> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>-10.0°C</td> <td>10.0°C</td> <td>0.0°C</td> </tr> </tbody> </table>			Min	Max	Fact. Set	-10.0°C	10.0°C	0.0°C	EXAMPLE : Same as Main Probe Cal.
	Min	Max	Fact. Set							
-10.0°C	10.0°C	0.0°C								

Description of parameters and functions.										
Sr.No.	Parameter (LCD Message)	Parameter setting method.								
13	COND PROBE CAL.	Function : To set Condensor probe calibration.								
	To change Cond Probe Cal. parameter, press the set key.		Use UP/DOWN keys to set desired value.							
	Range <table border="1"> <thead> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>-10°C</td> <td>10°C</td> <td>0°C</td> </tr> </tbody> </table>			Min	Max	Fact. Set	-10°C	10°C	0°C	EXAMPLE : Same as Main Probe Cal.
	Min	Max	Fact. Set							
-10°C	10°C	0°C								
14	CURRENT CAL.	Function : To set CT sensing calibration.								
	To change CT Cal. parameter, press the set key.		Use UP/DOWN keys to set desired value.							
	Range <table border="1"> <thead> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>-10Amp</td> <td>10Amp</td> <td>0Amp</td> </tr> </tbody> </table>			Min	Max	Fact. Set	-10Amp	10Amp	0Amp	EXAMPLE : If the actual current is 10A and if controller is showing 9A ,then set this parameter to 1A. Once out of this mode controller will display 10A.
	Min	Max	Fact. Set							
-10Amp	10Amp	0Amp								
15	HT POWER ON DLY	Function : This sets Power ON delay for high temperature alarm to avoid false alarms.								
	To change HT Power On Dly parameter, press the set key.		Use UP/DOWN keys to set desired value.							
	Range <table border="1"> <thead> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>0Min</td> <td>99Min</td> <td>20Min</td> </tr> </tbody> </table>			Min	Max	Fact. Set	0Min	99Min	20Min	
	Min	Max	Fact. Set							
0Min	99Min	20Min								
16	COND PROBE ACTIVE	Function : To enable or disable condenser probe.								
	To change Cond Probe Enable parameter, press the set key.		Use UP/DOWN keys to set desired value.							
	Range <table border="1"> <thead> <tr> <th>Min</th> <th>Max</th> <th>Fact. Set</th> </tr> </thead> <tbody> <tr> <td>Disable</td> <td>Enable</td> <td>Disable</td> </tr> </tbody> </table>			Min	Max	Fact. Set	Disable	Enable	Disable	Enable = Enables condenser probe control. Disble = Disables condenser probe control.
	Min	Max	Fact. Set							
Disable	Enable	Disable								

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
17	COND. SET TEMP.	Function : To set Condenser set temperature.	
To change Cond. set temp. parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
1°C	99°C	60°C	
EXAMPLE : If this parameter is set to 60°C then controller will trip the compressor on Condenser High temperature, if the Condenser sensor goes above 60°C.			
18	COND. SET DIFF.	Function : To set differential for Condenser.	
To change Cond. set differential parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
1°C	10°C	2°C	
Example: If condenser set temperature is set to 60°C and condenser will trip compressor when condenser temperature goes above 60°C and will reset only if temperature goes below 58°C.			
19	FAULT SENSE LOGIC	Function: To set tripping voltage of digital inputs.	
To change Fault sense logic parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0Vac	230Vac	230Vac	
0Vac = Controller will sense faults at 0 voltage level. 230Vac = Controller will sense faults at 230Vac .			

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
20	FAULT IN STAND BY	Function : This decides whether controller should display faults in stand by mode or not.	
To change Fault in Stand By parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Disable	Enable	Disable	
Disable = Faults are disabled in stand by mode. Enable = Faults are enabled in stand by mode.			
Note : Eventhough the fault sensing is disabled in stand by controller will display High temperature and low temperature alarms and sensor fail alarms.			
21	LP SENSING DLY	Function: To set LP fault sensing delay on compressor on.	
To change LP Sensing Dly parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
1sec	90sec	40 sec	
EXAMPLE: If this delay is set to 40seconds then the controller will ignore Lp fault for 40 seconds after compressor on it avoid false tripping of Compressor.			
22	HP/AFT RESET	Function : This parameter will set HP and AFT fault to Auto or Manual reset.	
To change HP-AFT Fault Reset parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Manual	Auto	Auto	
Auto = Sets HP-AFT faults as Auto ressetable. Manual = Sets HP-AFT faults as Manual ressetable. User need to press RST key To clear these faults.			

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
23	LP FAULT RESET	Function : This parameter will set LP fault to Auto or Manual reset.	
To change LP fault reset parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Manual	Auto	Auto	
		Auto = Sets LP faults as Auto resettable. Manual = Sets LP faults as Manual resettable. User need to press RST key To clear these faults.	
24	LIQUID LEVEL SENSOR	Function : This parameter enable / disables liquid level sensing.	
To change Liquid level parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Disable	Enable	Disable	
		Enable = This will enable liquid level sensing. Disable = This will disable liquid level sensing.	
25	PUMP RUN LOGIC	Function : This parameter configures pump to keep always on or on/off with compressor.	
To change Pump start parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Always On	With Comp	Always On	
		Always On = Pump will remain always on. With Comp = Pump will switch on/ off with compressor.	

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
26	COND RUN LOGIC	Function : This parameter configures Cond to keep always on or on/off with compressor.	
To change Cond Start parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Always On	With Comp	Always On	
		Always On = Condensor will remain always on. With Comp = Condensor will switch on/ off with compressor.	
27	COND START DLY.	Function: To set sensing delay of condenser on compressor ON.	
To change Cond Start Dly. parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
1sec	60sec	10 sec	
		If condenser is running with compressor And if this delay is set to 10seconds then condenser will switch on 10 seconds before compressor.	
28	CURRENT INPUT	Function: To enable / disable Current Sensing	
To change Ct Enable parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Disable	Enable	Disable	
		Enable = To Enable Current Sensing. Disable = To Disable Current Sensing.	

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
29	CURRENT LO LIMIT	Function : This parameter sets Low current limit for the compressor below which it will trip on "Underload" Fault.	
To change Ct LO reset parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0	Ct Hi-1	5Amp	
		Example : If this parameter is set to 5Amp then controller will trip compressor on Underload fault incase it is drawing less than 5 Ampere.	
30	CURRENT HI LIMIT	Function : This parameter sets High current limit for the compressor below which it will trip on "Overload" Fault.	
To change Ct HI parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Ct+Lo+1	20	15Amp	
		Example : If this parameter is set to 15Amp then controller will trip compressor on Overload fault incase it is drawing more than 15Ampere.	
31	CURRENT RETRIALS	Function : No. of retrials before sensing underload / overload fault in auto mode.	
To change Ct retrials parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0	10	3	
32	CURRENT FAULT RST	Function : To set current faults for Auto / Manual reset.	
To change Ct fault reset parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Manual	Auto	Manual	
		If CT fault is set to Auto then after no. of retrials compressor will trip on underload or overload fault and go to manual reset. If set to Manual in the first trip only controller will trip on underload or overload fault and go to manual reset.	




Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
33	CONFIG AUX I/P	Function : This configures AUX i/p as EWFS fault or as AUX i/p to switch off whole system	
To change CONFIG AUX I/P parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
AS EWFS	AS AUX	AS EWFS	
		This configures AUX i/p as EWFS fault or as AUX i/p to switch off whole system	
		AS AUX = It will set i/p as Auxiliary fault.	
		AS EWFS = It will set i/p as EWFS fault.	
34	EWFS STARTUP DLY	Function : It sets power on delay for EWFS fault sensing.	
To change EWFS Startup Dly parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0Sec	120Sec	10Sec	
35	EWFS NORMAL DLY	Function : It sets normal delay for EWFS fault sensing.This avoids false tripping due to water splashing.	
To change EWFS Normal Dly parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0Sec	90Sec	5Sec	

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
36	AUX I/P SETTING	Function : This parameter will set pump functioning incase of Auxilliary fault.	
To change Aux Input parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Pump ON	All OFF	Pump ON	
		Pump On = Will keep pump running in case of Auxilliary fault. All Off = Trip whole system on Auxilliary fault.	
37	PRECISION MODE	Function : To enable / disable Controller to function in precision mode.	
To change Precision Mode parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Disable	Enable	Disable	
		Example : If this mode is enabled, then the compressor will remain in the on state, while Precesion SV will switch on/off on the set point to maintain the temperature precisely.	
38	AUTOSTART	Function : To enable auto start of controller at power on.	
To change System Autostart parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Disable	Enable	Disable	
		Enable = Auto start controller at power on. Disable = Start Controller with power key.	
39	KEYPAD LOCK	Function : To lock keypad.	
To change Keypad Lock parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Disable	Enable	Enable	
		Enable = All parameter are locked to set values. Disable = Use can change the values.	

Description of parameters and functions.			
Sr.No.	Parameter (LCD Message)	Parameter setting method.	
40	CLEAR FAULT LOG	Function : To clear last fault history	
To change Clear Fault Log parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Store	Clear	Store	
		Clear = Clear all previous fault history Store = Store fault history	
		Example : If this parameter is set to 'Clear' then it will clear all previous faults saved in the memory. 'Store' will save last 15 faults.	
41	FACTORY DEFAULTS	Function : Revert to factory set parameter.	
To change Factory Setting parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Disable	Enable	Disable	
		To restore default settings of the controller. When set to Enable, all parameters are programmed to factory settings. Used to debug setting related problems.	
42	COMP RUN HRS	Function : To display total compressor working hours	
		Use UP/DOWN keys to set desired value.	
43	PUMP RUN HRS	Function: To display total pump working hours.	
		Use UP/DOWN keys to set desired value.	
44	CLR COMP RUN HRS	Function : To clear compressor run hours	
To change Clear Comp Run parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
Store	Clear	Store	
		Note : User need to connect prokey at the back of the controller before entering in to the program mode.	

Description of parameters and functions.				
Sr.No.	Parameter (LCD Message)	Parameter setting method.		
45	CLR PUMP RUN HRS	Function : To clear pump run hours.		
To change Clear Pump Run Hrs parameter, press the set key.		Use UP/DOWN keys to set desired value.		
Range		Note : User need to connect prokey at the back of the controller before entering in to the program mode.		
Min	Max			Fact. Set
Store	Clear			Store
46	ENTER YOUR NAME	Function : To set customer name to be displayed at controller power ON.		
To change Enter Your Name parameter, press the set key.		Use UP/DOWN keys to set desired value. Customer can set the name required to display at controller power ON.		
47	ENTER YOUR NO.	Function : To set customer service number.		
To change Enter Your No. parameter, press the set key.		Use UP/DOWN keys to set desired value. Customer can set service telephone number which will display at power ON.		
48	SET -EXIT UP/DOWN - SCROLL	Function : To end programming		
To end Program mode press set key.		Once the SET key is pressed the control goes into the normal mode and displays the temperature.		


Key Functions :

Key	Description
RST	Press for 4 seconds to reset HP, LP, AFT faults in manual reset.
	Used in program mode and set mode to increment parameter value. Used to view to Antifreeze (AFT) Temperature & Condenser Temperature.
	Used to enter into the program mode. Used in program mode and set mode to decrement parameter value.
SET	In program mode and set mode used to set the changed value of parameter or to enter into set mode.
 + SET	Press DOWN PRG and SET keys simultaneously to start or stop the chiller.


Technical Data

Housing	: ABS Plastic
Dimensions	: Front - 106.2 x 50 mm Depth- 59 mm
Panel Cutout	: 92 X 45 mm
Mounting	: Flush panel mounting
Protection	: IP54 Frontal
Connection	: Plugable Screw terminal blocks. ≤ 2.5mm ² one wire/terminal only.
Display	: 16x2 LCD
Data Storage :	Non-Volatile EEPROM Memory
Power Input	: 230Vac +/-10%, 50Hz
Operating Temp	: 5°C to 50°C(non-condensing)
Storage Temp	: -20°C to 70°C(non-condensing)
Input	: NTC Probe, SZ-N75
Range	: -30.0°C to +50.0°C
Resolution	: 0.1°C
Accuracy	: +/-1°C
Probe Tolerance	: +/-0.3°C AT 25°C
All Relay	: 5A / 250Vac
Current Input	: 0 to 20Amp.
Resolution	: 0.1Amp.

Suggested Wiring Diagram



Panel Cutout & Dimensions



Installation

Fixing and dimensions of panel models :To fix the unit, slide the side lock^① through the guides ^② as per the position shown in the figure. Move the side lock in the direction of the arrow, it permits to move the fastener in the opposite direction of the arrow^③ Fit the screw in the side lock in direction of the arrow to hold the controller in the panel.

Controller

Controller should be installed in a place protected by vibration, water and corrosive gasses and where ambient temperature does not exceed the values specified in the technical data.

Probe

To give a correct reading, the probe must be installed in a place protected from thermal influences, which may affect the temperature to be controlled.

CAUTION

WIRING : The probe and its corresponding wires should never be installed in a conduit next to control or power supply lines. The electrical wiring should be done as shown in the diagram. The power supply circuit should be connected to a protection switch. The terminals admit wires of upto 2.5sq mm.

WARNING : Improper wiring may cause irreparable damage and personal injury. Kindly ensure that wiring is done by qualified personnel only.

Maintenance : Cleaning : Clean the surface of the controller with a soft moist cloth. Do not use abrasive detergents, petrol, alcohol or solvents.

Notice

The information in this document is subject to change in order to improve reliability, design or function without prior notice and does not represent a commitment on the part of the company. In no event will the company be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company.

Disclaimer

This manual & its contents remain the sole property of PVR Controls, India and shall not be reproduced or distributed without authorization. Although great care has been taken in the preparations of this document, the company or its vendors in no event will be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company. PVR Controls reserves the right to make and changes or improvements without prior notice.

Warranty

This product is warranted against defects in materials and workmanship for a period of one year from the date of purchase. During the warranty period, product determined by us to be defective in form or function will be repaired or, at our option, replaced at no charge. This warranty does not apply if the product has been damaged by accident, abuse, and misuse or as a result of service or modification other than by the company. This warranty is in lieu of any other warranty expressed or implied. In no event shall the company be held liable for incidental or consequential damages, such as lost revenue or lost business opportunity arising from the purchase of this product.

OUR OTHER PRODUCTS



INDIA

Cold Room Controller
Chiller Controller
Two Compressors Controller
Heating Controller
Humidity Controller
Pressure Controller



Ball Valves
Globe Valves
Hand Valves
Flow Switches
Solenoid Valves