



INDIA  
www.pvrcontrols.com

# OPERATING INSTRUCTIONS



VMRC- 10/1/3/3-CT

## GENERAL DESCRIPTION

VMRC-10/3 is three phase LVM and VMRC-10/1 is single phase LVM.

VMRC-10/3 is three phase Line voltage monitor (LVM) used to protect device from Single Phasing, voltage unbalance, phase reversal and under/over voltage. It shows real time voltages between phase and neutral.

VMRC-10/3-CT is three phase Line voltage monitor (LVM) with an additional overload protection facility with external CT Board.

VMRC-10/1 Single phase LVM used to protect device from under/over voltage faults it shows real time voltages readings.

There is an alarm relay given to extend the faults. Features are easily understood by examples in the instruction below.

1

## INDEX

Para.	Page	Description	A	B	C
	4	To go to program mode.			
<i>rEF</i>	5	To set Reference Voltage	✓	✓	✓
<i>oU</i>	6	To set Overvoltage Limits.	✓	✓	✓
<i>uU</i>	7	To set Undervoltage Limits.	✓	✓	✓
<i>unb</i>	8	To set Un Balance Value.		✓	✓
<i>ttd</i>	9	To set Time Delay.	✓	✓	✓
<i>tdr</i>	10	To set Fault Recover Delay.	✓	✓	✓
<i>oL1</i>	11	To set Current Overload1 Value.			✓
<i>dL1</i>	12	To set Current sensing Delay for dL1.			✓
<i>oL2</i>	13	To set Current Overload2 Value.			✓
<i>dL2</i>	14	To set Current sensing Delay for dL2.			✓
<i>CCb</i>	15	To set Current Calibration.			✓
<i>CrY</i>	16	To set Calibration of Voltage.	✓	✓	✓
<i>CYb</i>	17	To set Calibration of Voltage.		✓	✓
<i>Crb</i>	18	To set Calibration of Voltage.		✓	✓
<i>ALn</i>	19	To CT Alarm type.			✓
<i>dSP</i>	20	To set Display mode.		✓	✓
<i>FS</i>	21	To Restore factory defaults.	✓	✓	✓
<i>End</i>	22	End programming.	✓	✓	✓

2

## INDEX

Para.	Page	Description	A	B	C
	23	Technical Data for VMRC-10/1.			
	24	Front View & Connection Diagram.			
	25	Technical Data for VMRC-10/3.			
	26	Front View & Connection Diagram.			
	27	Technical Data for VMRC-10/3-CT.			
	28	Front View & Connection Diagram.			
	29	Drinrail Technical Data for VMRC-10/3.			
	30	Drinrail Front View & Connection Diagram.			

### NOTE :

- A : VMRC 10/1 (Single Phase)
- B : VMRC 10/3 (Three Phase)
- C : VMRC 10/3-CT (Three Phase with CT)

3

Function: To go to program mode.

Press and hold PRG / SET Key for 2 seconds.

PRG  
SET

Display will show *rEF* & flash. To go to other parameters, use UP/DOWN keys.

4

$rEF$ Parameter	Function: To set Reference voltage.		
To change the $rEF$ parameter, press set key.	Use UP/DOWN keys to set desired value. Base reference voltage to calculate under voltage and over voltage values.		
<b>VMRC-10/1</b>			
Min	Max	Fac.	
220V	250V	240V	
<b>VMRC-10/3 VMRC-10/3-CT</b>			
Min	Max	Fac.	
381V	415V	415V	
Min and Max value will change according to display type for settings. <b>Example : L-L, Min= 381 Max= 415.</b>			

5

$oV$ Parameter	Function: To set Overvoltage Limits.		
To change the $oV$ parameter, press set key.	Use UP/DOWN keys to set desired value. If the a/c voltages goes above this limit will trip respective a/c on Overvoltage("Ov") fault.		
<b>VMRC-10/1</b>			
Min	Max	Fac.	
5V	75V	20V	
<b>VMRC-10/3 VMRC-10/3-CT</b>			
Min	Max	Fac.	
5V	75V	35V	
<b>Example :</b> Over voltage is calculated depending on Reference voltage + Ov value. i.e, Ov Set Point = Ref + Ov , When controller trip on Ov Fault it will recover when input voltage fall below (Ref + (Ov /2)).			

6

$uV$ Parameter	Function: To set Undervoltage Limits.		
To change the $uV$ parameter, press set key.	Use UP/DOWN keys to set desired value. If the a/c voltages goes below this limit will trip respective a/c on undervoltage("Uv") fault.		
<b>VMRC-10/1</b>			
Min	Max	Fac.	
5V	75V	20V	
<b>VMRC-10/3 VMRC-10/3-CT</b>			
Min	Max	Fac.	
5V	75V	35V	
<b>Example :</b> Under voltage is calculated depending on Reference voltage - Uv value. i.e Uv Set Point = Ref - Uv , When controller trip on Uv Fault it will recover when input voltage above (Ref - (Uv /2)).			

7

$unb$ Parameter	Function: To set Un Balance value. (Only for 10/3 & 10/3-CT)		
To change the $unb$ parameter, press set key.	Use UP/DOWN keys to set desired value. Unbalance fault raised when voltage difference between any of two phases goes above Unb value and recovers when the difference is less than (UNB/2).		
<b>VMRC-10/3</b>			
Min	Max	Fac.	
10V	120V	60V	
<b>VMRC-10/3-CT</b>			
Min	Max	Fac.	
10V	120V	60V	

8

$ttd$ Parameter	Function : To set time delay.		
To change the $ttd$ parameter, press the set key.	Use UP/DOWN keys to set desired value. Time delay provided to avoid false triggering, when any fault last more than TTD value then only fault is raised and this fault is applicable to Under voltage, Over voltage and Unbalance fault.(i.e., In case of Phase Loss or Phase sequence fault alarm will come immediately).		
Min	Max	Fac.	
0Sec	60Sec	10Sec	

9

$tdr$ Parameter	Function : To set fault recover delay. (Only for 10/3 & 10/3-CT)		
To change the $tdr$ parameter, press the set key.	Use UP/DOWN keys to set desired value. Time delay provided to add delay in fault recover time, to avoid sudden fault triggering and reset.		
Min	Max	Fac.	
0Sec	60Sec	10Sec	

10

<b>oL1</b> Parameter			Function : To set current overload1 value. (Only for 10/3-CT)
To change the oLd1 parameter, press the set key.			Use UP/DOWN keys to set desired value.  If current input crosses this value then depending on dL1 delay parameter overload fault get set.
Min	Max	Fac.	
1.0A	oL2 -1.0A	15.0A	

11

<b>dL1</b> Parameter			Function : To set current sensing delay for oL1. (Only for 10/3-CT)
To change the dL1 parameter, press the set key.			Use UP/DOWN keys to set desired value.  When current input crosses oL1 value, after dL1 time delay, oL fault set and alarm relay get activated.
Min	Max	Fac.	
0Sec	120Sec	20Sec	

12

<b>oL2</b> Parameter			Function : To set current overload2 value. (Only for 10/3-CT)
To change the oL2 parameter, press the set key.			Use UP/DOWN keys to set desired value.  If current input crosses this value then depending on dL2 delay parameter overload fault get set.
<b>20A</b>			
Min	Max	Fac.	
oL1 +1.0A	20.0A	18.0A	
<b>50A</b>			
Min	Max	Fac.	
oL1 +1.0A	50.0A	25.0A	

13

<b>dL2</b> Parameter			Function : To set current sensing delay for oL2. (Only for 10/3-CT)
To change the dL2 parameter, press the set key.			Use UP/DOWN keys to set desired value.  When current input crosses oL2 value, after dL2 time delay, oL fault set and alarm relay get activated.
Min	Max	Fac.	
0Sec	120Sec	10Sec	

14

<b>CCb</b> Parameter			Function : To set current calibration. (Only for 10/3-CT)
To change the ccb parameter, press the set key.			Use UP/DOWN keys to set desired value.  This parameter provided to calibrate current reading.
Min	Max	Fac.	
-2.0A	2.0A	0.0A	

15

<b>CrY/E-r</b> Parameter			Function : To set calibration of voltage r-Y or r phase. (Only for 10/3, 10/3-CT)
To change CrY parameter, press the SET key.			Use UP/DOWN keys to set desired value.  This parameter provided to calibration voltage reading.  When dsP is L-L CrY value get set. When dsP is L-n C-r value get set.
Min	Max	Fac.	
-30V	30V	00V	

16

<i>C<sub>yb</sub>/C-Y</i> Parameter			Function : To set calibration of voltage Y-b or Y phase. (Only for 10/3, 10/3-CT)
To change C <sub>yb</sub> parameter, press the SET key.			Use UP/DOWN keys to set desired value.  This parameter provided to calibration voltage reading.  When dsP is L-L C <sub>yb</sub> value get set. When dsP is L-n C-Y value get set.
Min	Max	Fac.	
-15V	15V	00V	

17

<i>C<sub>rb</sub>/C-b</i> Parameter			Function : To set calibration of voltage r-b or b phase. (Only for 10/3, 10/3-CT)
To change C <sub>rb</sub> parameter, press the SET key.			Use UP/DOWN keys to set desired value.  This parameter provided to calibration voltage reading.  When dsP is L-L C <sub>rb</sub> value get set. When dsP is L-n C-b value get set.
Min	Max	Fac.	
-15V	15V	00V	

18

<i>AL<sub>n</sub></i> Parameter			Function : To CT Alarm type. (Only for 10/3-CT)
To change the AL <sub>n</sub> parameter, press the set key.			Use UP/DOWN keys to set desired value.  Auto Mode = Controller will reset after fault is reset. Manual Mode = This mode incase of OL fault controller will go manual mode.  Retrials Mode = In this mode controller will do set number of retrials and then go to manual mode.
Min	Max	Fac.	
Aut	rtr	Aut	

19

**Note : Press RST key to reset CT Alarm.**

<i>dsP</i> Parameter			Function : To set view display mode. (Only for 10/3, 10/3-CT)
To change the dsP parameter, press the set key.			Use UP/DOWN keys to set desired value.  There are two type of display output, Line to Line Voltage (L-L) and Line to Neutral (L-n), Depending on this parameter REF parameter also changes.
Min	Max	Fac.	
L-L	L-n	L-L	

20

<i>F5</i> PARAMETER			Function : To restore the default settings of the controller.
To change the FS parameter, press the set key.			Use UP/DOWN keys to set desired value. When set to 1, all parameters are programmed to factory values.
Min	Max	Fac.	
no	YES	no	

21

<i>End</i> Parameter			Function : To end programming.
To end programming, press the SET key.			Once the set key is pressed, the controller goes into the normal mode and displays the voltage readings.

22

**Technical Data for  
Single Phase Voltage Monitor (VMRC- 10/1)**

**Main Features** : Voltage Monitoring.  
Uv and Ov Detection.  
Settable Uv and Ov Parameter.


**Input** : Single Phase AC supply.  
**Output** : Alarm Relay : 5A Resistive.

**Application** : Under voltage and Over voltage detection.

**General Specification :**  
Input Voltage Range from 100VAC to 265VAC.  
Mounting : Din rail mounting.  
Connections : Screw terminals :  $\leq 2.5\text{sqmm}$  one wire/  
terminal only.

23

**Front View & Connetion Diagram for  
Single Phase Voltage Monitor (VMRC- 10/1)**



24

**Technical Data for  
Three Phase Voltage Monitor (VMRC- 10/3)**

**Main Features** : Voltage Monitoring.  
Phase Sequence Monitoring.  
Phase Loss and Phase Unbalance detection.  
Uv and Ov Detection.  
Settable Uv and Ov Parameter.


**Input** : R Y B Phases and Neutral Input.  
**Output** : Alarm Relay : 5A Resistive.

**Application** : Voltage and phase sequence monitoring and controlling.  
Under voltage and Over voltage detection.

**General Specification :**  
Input Voltage Range from 173VAC to 458VAC.  
Mounting : Din rail mounting.  
Connections : Screw terminals :  $\leq 2.5\text{sqmm}$  one wire/  
terminal only.

25

**Front View & Connetion Diagram for  
Three Phase Voltage Monitor (VMRC- 10/3)**



26

**Technical Data for  
Three Phase Voltage Monitor (VMRC- 10/3-CT)**

**Main Features** : Voltage Monitoring.  
Phase Sequence Monitoring.  
Phase Loss and Phase Unbalance detection.  
Uv and Ov Detection.  
Settable Uv and Ov Parameter.

**Input** : R Y B Phases and Neutral Input.  
3 CT Board 20Amp.  
1 CT Board 50Amp.


**Output** : Alarm Relay : 5A Resistive.

**Application** : Voltage and phase sequence monitoring and controlling.  
Under voltage, Over voltage and Overload detection.

**General Specification :**  
Input Voltage Range from 173VAC to 458VAC.  
Mounting : Din rail mounting.  
Connections : Screw terminals :  $\leq 2.5\text{sqmm}$  one wire/  
terminal only.

27

**Front View & Connetion Diagram for  
Three Phase Voltage Monitor (VMRC- 10/3-CT)**






28

### Technical Data for Three Phase Voltage Monitor (VMRC- 10/3)


- Main Features** : Voltage Monitoring.  
Uv and Ov Detection.  
Settable Uv and Ov Parameter.
- Input** : Three Phase AC supply with Neutral.
- Output** : Alarm Relay : 5A Resistive.
- Application** : Under voltage and Over voltage detection.
- General Specification** :  
Input Voltage Range from 100VAC to 265VAC.
- Mounting** : Din rail mounting.
- Connections** : Screw terminals :  $\leq 2.5\text{sqmm}$  one wire/terminal only.

29


### Front View & Connetion Diagram for Three Phase Voltage Monitor (VMRC- 10/3)




30




31



32



33



34

**Controller :** Controller should be installed in a place protected by vibration, water and corrosive gasses and where ambient temperature does not exceed the values specified in the technical data.

**CAUTION**

**WIRING :** The alarm wires should never be installed in a conduit next to control or power supply lines. The electrical wiring should be done as shown in the diagram. The power supply circuit should be connected to a protection switch. The terminals admit wires of upto 2.5sq. mm.

**WARNING :** Improper wiring may cause irreparable damage and personal injury. Kindly ensure that wiring is done by qualified personnel only.

**Maintenance :** Cleaning : Clean the surface of the controller with a soft moist cloth. Do not use abrasive detergents, petrol, alcohol or solvents.

**Notice :** The information in this document is subject to change in order to improve reliability , design or function without prior notice and does not represent a commitment on the part of the company. In no event will the company be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company.

**Disclaimer :** This manual & its contents remain the sole property of PVR CONTROLS, India and shall not be reproduced or distributed without authorization. Although great care has been taken in the preparation of this document, the company or its vendors in no event will be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company. PVR CONTROLS, reserves the right to make and changes or improvements without prior notice.

**Warranty:** This product is warranted against defects in materials and workmanship for a period of one year from the date of purchase. During the warranty period, product determined by us to be defective in form or function will be repaired or, at our option, replaced at no charge. This warranty does not apply if the product has been damaged by accident, abuse, and misuse or as a result of service or modification other than by the company. This warranty is in lieu of any other warranty expressed or implied. In no event shall the company be held liable for incidental or consequential damages, including lost revenue or lost business opportunity arising from the purchase of this product..

**OUR OTHER PRODUCTS**



INDIA

- Cold Room Controller
- Chiller Controller
- Two Compressors Controller
- Heating Controller
- Humidity Controller
- Pressure Controller



- Ball Valves
- Globe Valves
- Hand Valves
- Flow Switches
- Solenoid Valves